

⚠ WARNING

- 4 Generally, when multi-byte data are read or written at once among the following two or more applications including network functions, the coherency of the read multi-byte data (in other words, reading all latest data at once) is not guaranteed. To ensure the coherency of the multi-byte data, prepare flags to notify the completion of reading or writing process that is separated from the entity of the data and make the handshaking process to access the data by using the flags.

Data List Table

Category	Data
General data for CNC	Parameter, Tool compensation value and related data, Work zero offset value and related data, Workpiece coordinate system shift value and related data, Macro variable, P-CODE variable, Program and related data, Tool management function data, Tool life management data, Error compensation related data , Overtravel check (Interference check) related data , Software operator's panel related data
PMC data	PMC signal, PMC parameter
Data for Laser, Punch press or Wire cut	Tool data for punch press and related data, Safety zone data and related data, Laser cutting condition data and related data, Laser oscillator setting data and related data, Wire consumption compensation data, Guide position compensation data, Workpiece leveling data
Other data	Parameters for Data Server, Parameters for network setting

List Table of Applications and Network Functions

Category	Functions
Applications	FANUC OPC Server , PMC Ladder, Macro Executor, C Language Executor, FANUC PICTURE, FOCAS2
Network functions	FL-net, EtherNet/IP, PROFINET, Modbus/TCP, PROFIBUS-DP, DeviceNet, CC-Link

- 5 CNC has functions that read or write PMC signals in other than the G/F address. Be careful enough if the above mentioned applications and network read or write PMC signals used by these functions. When reading or writing the same PMC signal, applications or CNC functions may work in an unexpected manner. For the relevant CNC functions, refer to "LIST OF FUNCTIONS USING PMC SIGNALS OTHER THAN G/F ADDRESS " in Appendix in the CONNECTION MANUAL (FUNCTION) of the relevant CNC.

							Title	FANUC OPC Server Operator's Manual	
							Draw	A-40622-00001EN	
05	2020.09.30	R.Imada	The security function of FOCAS2 added.	T.Hosaka					
04	2018.06.21	S.Matsukura	Data type added.						
03	2017.12.25	T.Hosaka	OPC UA support						
02	2016.01.13	T.Hosaka	Old CNC support and data type added.						
Ed.	Date	Design	Description			FANUC CORPORATION		Sheet.	8/167
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata		

1

General

This chapter explains the organization of this manual and how to read this manual.

1.1 COMPOSITION

This manual consists of the following parts:

SAFETY PRECAUTIONS

This section describes the precautions to be observed when reading this manual.

I. GENERAL

This part describes the chapter organization, applicable models, related manuals, and general of the FANUC OPC Server.

II. INSTALLATION

This part describes how to install and uninstall. Please read carefully before installation.

III. SETTING

This part describes the setting items necessary to use each function.

1.2 CNC Model name

The abbreviations of CNC model name in the following table are sometimes used in text descriptions.

Model name	Abbreviation		
FANUC Series 30i-MODEL A	Series 30i -A	Series 30i/31i/32i -A	
FANUC Series 31i-MODEL A	Series 31i -A		
FANUC Series 31i-MODEL A5	Series 32i -A		
FANUC Series 30i-MODEL B	Series 30i -B	Series 30i/31i/32i -B	Series 30i/31i/32i/35i -B or 30i/31i/32i/35i -B
FANUC Series 31i-MODEL B	Series 31i -B		
FANUC Series 31i-MODEL B5	Series 32i -B		
FANUC Series 32i-MODEL B	Series 32i -B	Series 35i -B	
FANUC Series 35i-MODEL B	Series 30i -B Plus	Series 30i/31i/32i -B Plus or 30i/31i/32i -B Plus	
FANUC Series 30i-MODEL B Plus	Series 31i -B Plus		
FANUC Series 31i-MODEL B5 Plus	Series 32i -B Plus		
FANUC Series 31i-MODEL B Plus	Series 32i -B Plus	Power Motion <i>i</i> -A	PMi -A
FANUC Series 32i-MODEL B Plus	Power Motion <i>i</i> -A	Series 0i-D	0i-D
FANUC Power Motion <i>i</i> -MODEL A	Series 0i-D	Series 0i-F	0i-F
FANUC Series 0i-MODEL D	Series 0i-F	Series 0i-B	0i-B
FANUC Series 0i-MODEL F	Series 0i-F Plus		
FANUC Series 0i-MODEL F Plus	Series 0i-B	Series 0i-C	0i-C
FANUC Series 0i-MODEL B	Series 0i-C		
FANUC Series 0i-MODEL C	Series 16i -A	Series 16i/18i/21i -A	
FANUC Series 16i-MODEL A	Series 18i -A		
FANUC Series 18i-MODEL A	Series 21i -A		
FANUC Series 21i-MODEL A	Series 16i -B	Series 16i/18i/21i -B	
FANUC Series 16i-MODEL B	Series 18i -B		
FANUC Series 18i-MODEL B	Series 21i -B		
FANUC Series 21i-MODEL B	Series 21i -B		

				Title		FANUC OPC Server Operator's Manual	
				Draw		A-40622-00001EN	
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka				
04	2018.06.21	S.Matsukura	Data type added.				
03	2017.12.25	T.Hosaka	OPC UA support				
02	2016.01.13	T.Hosaka	Old CNC support and data type added.				
Ed.	Date	Design	Description				
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata
FANUC CORPORATION						Sheet.	10/167

Manual name	Specification number	
PARAMETER MANUAL	B-64580EN	
Related to Series 0i-D		
DESCRIPTIONS	B-64302 EN	
CONNECTION MANUAL (HARDWARE)	B-64303 EN	
CONNECTION MANUAL (FUNCTION)	B-64303 EN -1	
Common to Lathe System / Machining Center System OPERATOR'S MANUAL	B-64304 EN	
For Lathe System OPERATOR'S MANUAL	B-64304 EN -1	
For Machining Center System OPERATOR'S MANUAL	B-64304 EN -2	
MAINTENANCE MANUAL	B-64305 EN	
PARAMETER MANUAL	B-64310 EN	
OPERATION AND MAINTENANCE HANDBOOK	B-64307 EN	
Related to Series 0i-F		
DESCRIPTIONS	B-64602 EN	
CONNECTION MANUAL (HARDWARE)	B-64603 EN	
CONNECTION MANUAL (FUNCTION)	B-64603 EN -1	
CONNECTION MANUAL (FUNCTION 0i-PF)	B-64623 EN	
Common to Lathe System / Machining Center System OPERATOR'S MANUAL	B-64604 EN	
OPERATOR'S MANUAL (0i-PF)	B-64624 EN	
For Lathe System OPERATOR'S MANUAL	B-64604 EN -1	
For Machining Center System OPERATOR'S MANUAL	B-64604 EN -2	
MAINTENANCE MANUAL	B-64605 EN	
PARAMETER MANUAL	B-64610 EN	
PARAMETER MANUAL (0i-PF)	B-64630 EN	
Related to Series 0i-F Plus		
DESCRIPTIONS	B-64692 EN	
CONNECTION MANUAL (HARDWARE)	B-64693 EN	
CONNECTION MANUAL (FUNCTION)	B-64693 EN -1	
Common to Lathe System / Machining Center System OPERATOR'S MANUAL	B-64694 EN	
For Lathe System OPERATOR'S MANUAL	B-64694 EN -1	
For Machining Center System OPERATOR'S MANUAL	B-64694 EN -2	
MAINTENANCE MANUAL	B-64695 EN	
PARAMETER MANUAL	B-64700 EN	
Related to Series 16i/18i-A		
DESCRIPTIONS	B-63002EN	
CONNECTION MANUAL (HARDWARE)	B-63003EN	
CONNECTION MANUAL (FUNCTION)	B-63003EN-1	
16i/18i -MA OPERATOR'S MANUAL	B-63014EN	
16i/18i -TA OPERATOR'S MANUAL	B-63004EN	
MAINTENANCE MANUAL	B-63005EN	
PARAMETER MANUAL	B-63010EN	
Related to Series 21i-A		
DESCRIPTIONS	B-63002EN	
CONNECTION MANUAL (HARDWARE)	B-63083EN	
CONNECTION MANUAL (FUNCTION)	B-63003EN-1	
21i -MA OPERATOR'S MANUAL	B-63094EN	
21i -TA OPERATOR'S MANUAL	B-63084EN	
MAINTENANCE MANUAL	B-63085EN	
PARAMETER MANUAL	B-63090EN	
Related to Series 16i/18i/21i-B		
DESCRIPTIONS	B-63522EN	

					Title	FANUC OPC Server Operator's Manual			
					Draw	A-40622-00001EN			
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka						
04	2018.06.21	S.Matsukura	Data type added.						
03	2017.12.25	T.Hosaka	OPC UA support						
02	2016.01.13	T.Hosaka	Old CNC support and data type added.						
Ed.	Date	Design	Description			FANUC CORPORATION		Sheet.	12/167
Date	2015.09.25	Desig.	T.Hosaka	Check					

Manual name	Specification number	
CONNECTION MANUAL (HARDWARE)	B-63523EN	
CONNECTION MANUAL (FUNCTION)	B-63523EN-1	
16i/18i –MB OPERATOR'S MANUAL	B-63534EN	
16i/18i –TB OPERATOR'S MANUAL	B-63524EN	
21i –MB OPERATOR'S MANUAL	B-63614EN	
21i –TB OPERATOR'S MANUAL	B-63604EN	
MAINTENANCE MANUAL	B-63525EN	
16i/18i –B PARAMETER MANUAL	B-63530EN	
21i-B PARAMETER MANUAL	B-63610EN	
OPERATION AND MAINTENANCE HANDBOOK	B-63527EN	
Related to Series 0i-B		
DESCRIPTIONS	B-63832EN	
CONNECTION MANUAL (HARDWARE)	B-63833EN	
CONNECTION MANUAL (FUNCTION)	B-63833EN-1	
0i-TB OPERATOR'S MANUAL	B-63834EN	
0i-MB OPERATOR'S MANUAL	B-63844EN	
MAINTENANCE MANUAL	B-63835EN	
PARAMETER MANUAL	B-63840EN	
Related to Series 0i-C		
DESCRIPTIONS	B-64112EN	
CONNECTION MANUAL (HARDWARE)	B-64113EN	
CONNECTION MANUAL (FUNCTION)	B-64113EN-1	
0i-TC OPERATOR'S MANUAL	B-64114EN	
0i-MC OPERATOR'S MANUAL	B-64124EN	
0i-TTC OPERATOR'S MANUAL	B-64284EN	
MAINTENANCE MANUAL	B-64115EN	
PARAMETER MANUAL	B-64120EN	
Related to Power Mate i-D/H		
DESCRIPTIONS	B-63172EN	
CONNECTION MANUAL (HARDWARE)	B-63173EN	
CONNECTION MANUAL (FUNCTION)	B-63173EN-1	
OPERATOR'S MANUAL	B-63174EN	
MAINTENANCE MANUAL	B-63175EN	
PARAMETER MANUAL	B-63180EN	
OPERATION AND MAINTENANCE HANDBOOK	B-63177EN	
PMC		
30i/31i/32i/35i –B PMC PROGRAMMING MANUAL	B-64513EN	
PMC LADDER LANGUAGE PROGRAMMING MANUAL	B-61863EN	
Network		
30i/31i/32i–A/B 35i –B Power Motion i –A 0i –F	B-64014EN	
Fast Ethernet / Fast Data Server OPERATOR'S MANUAL		
FAST Ethernet Board FAST DATA SERVER OPERATOR'S MANUAL	B-63644EN	
Dual Check Safety		
Dual Check Safety CONNECTION MANUAL	B-64483EN-2	

						Title	FANUC OPC Server Operator's Manual		
						Draw	A-40622-00001EN		
05	2020.09.30	R.Imada	The security function of FOCAS2 added.	T.Hosaka					
04	2018.06.21	S.Matsukura	Data type added.						
03	2017.12.25	T.Hosaka	OPC UA support						
02	2016.01.13	T.Hosaka	Old CNC support and data type added.						
Ed.	Date	Design	Description			FANUC CORPORATION	Sheet.	13/167	
Date	2015.09.25	Desig.	T.Hosaka	Check	Apprv.				K.Murata

2

Overview of FANUC OPC Server

This chapter describes the general information about the overview of the FANUC OPC Server. Hereafter, "FANUC OPC Server" might be described as "OPC Server", and "FANUC OPC Configurator" as "OPC Configurator".

2.1 Introduction to FANUC OPC Server


FANUC OPC Server is an OPC Server software to access the data of FANUC CNC and to expose it to the OPC interface. The third party software with OPC Client function can read and write the data of CNC through FANUC OPC Server.

Up to 100 CNCs and up to 10 OPC clients can be connected to FANUC OPC Server.

FANUC OPC Server supports OPC-DA standard 3.0, 2.0, 1.0a, and OPC-UA standard.

FANUC OPC Configurator is a tool to configure FANUC OPC Server.

FOCAS/Ethernet is used for the communication between FANUC OPC Server and CNC.



2.2 Supported CNC

The following CNCs are supported.

One of the Embedded Ethernet, Multi-function Ethernet or Fast Ethernet board is required.

- Series 30i/31i/32i-A
- Series 30i/31i/32i/35i-B , Series 30i/31i/32i-B Plus
- Series 0i-TD/MD
- Series 0i-TF/MF , Series 0i-TF/MF Plus
- Power Motion i-A
- Series 16i/18i/21i-A/B

				Title	FANUC OPC Server Operator's Manual			
				Draw	A-40622-00001EN			
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka					
04	2018.06.21	S.Matsukura	Data type added.					
03	2017.12.25	T.Hosaka	OPC UA support					
02	2016.01.13	T.Hosaka	Old CNC support and data type added.					
Ed.	Date	Design	Description		FANUC CORPORATION		Sheet.	14/167
Date	2015.09.25	Desig.	T.Hosaka	Check				

- Series Oi-B/C
- PowerMate i-D/H

2.3 Supported CNC data

The following types of CNC data are supported.

- CNC System Information (CNC Series, CNC Type, CNC controlled Axis Count/Path)
- Tool Offsets
- Work Offsets
- Program Data
(Main Program Number, Main Program Comment, Active Program Number, Active Program Comment)
- Custom Macro Variable
(Local Variable, Common Variable, Embedded Macro Variable, System Variable)
- Alarm Information
(Alarm Messages, Alarm Number)
- Axis Name
- Position Information
(Absolute Position, Distance to go Position, Machine Position, Relative Position)
- PMC Data
(PMC Bit, PMC Byte, PMC 2Byte, PMC 4Byte)
- PMC Alarm
(PMC Alarm Messages, PMC Alarm Number)
- Number of Machined Parts
- P-CODE
(Control Variable, Variable, Extended Variable)
- Operator Messages
- CNC Status
(Mode, Operation, Emergency)

2.4 Number of Point

The data exchanged to CNC is called "point" at OPC Server.

In the FANUC OPC server, maximum 10,000 points can be set. This is a total of all connected CNCs.

NOTE

The performance of the OPC server depends on the following conditions. The performance means how many points can be renewed at how much intervals.

- The performance of the PC where OPC Server runs
- Number of connected CNC and OPC client

When deciding the above-mentioned conditions, please execute the preliminary test to confirm that the performance of OPC Server achieves the necessary performance.

2.5 Update Time of Point

The minimum value for the update time of point is 100ms.

						Title	FANUC OPC Server Operator's Manual			
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka			Draw	A-40622-00001EN			
04	2018.06.21	S.Matsukura	Data type added.							
03	2017.12.25	T.Hosaka	OPC UA support							
02	2016.01.13	T.Hosaka	Old CNC support and data type added.				FANUC CORPORATION		Sheet.	15/167
Ed.	Date	Design	Description							
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata			

II . INSTALLATION

				Title	FANUC OPC Server Operator's Manual		
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka				
04	2018.06.21	S.Matsukura	Data type added.	Draw	A-40622-00001EN		
03	2017.12.25	T.Hosaka	OPC UA support				
02	2016.01.13	T.Hosaka	Old CNC support and data type added.				
Ed.	Date	Design	Description	FANUC CORPORATION			Sheet.
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata
							17/167

1 Installation

This chapter describes the software installation of FANUC OPC Server software.

1.1 Shipping Items

Please confirm that you received the following items.

- The installation media of this software
- The paper where the serial number is printed

Please enter the serial number on your FANUC OPC Registration screen after you installed the software. The input of the serial number is necessary to run this software.

1.2 Preparation


This tool communicates with CNC by using the TCP/IP protocol of Ethernet.

At the PC where you install this tool, please confirm the followings.

- TCP/IP function is installed.
- IP address, subnet mask, and if necessary the default gateway, of the PC are specified.
- If your computer is not connected to the Internet, to disable the check for publisher's certificate revocation of digital signature.

Open the [Control Panel], click the [Internet Options], Open the Internet Properties.

Select the [Advanced] tab, uncheck the [check for publisher's certificate revocation], and then click the [OK] button



						Title	FANUC OPC Server Operator's Manual					
						Draw	A-40622-00001EN					
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka									
04	2018.06.21	S.Matsukura	Data type added.									
03	2017.12.25	T.Hosaka	OPC UA support									
02	2016.01.13	T.Hosaka	Old CNC support and data type added.									
Ed.	Date	Design	Description							FANUC CORPORATION	Sheet.	18/167
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata					

NOTE

On a PC that does not connect to the Internet, if that is the check box for [Check for publisher's certificate revocation], it takes a long time to start of FANUC OPC Configurator.

1.3 Installation

This section details the steps of software installation for the Windows 7 operating system. Installation for other OS is almost the same.

NOTE

- 1 To install the software, you must have the administrator user name and password.
- 2 Before installing, please close all running programs.
- 3 The following software is used. If it is not installed, it is installed automatically.
 - Microsoft .NET Framework 4 Client Profile
 - Microsoft .NET Framework 4 Extended
 - Microsoft Visual Studio C++ 2010 x86 Redistributable
 - Windows Installer 4.5 for Windows XP SP2 and later (x86) (Windows XP only)


The standard installation steps install both the FANUC OPC Server and the FANUC OPC Configurator, the configuration tool for the OPC Server.

When "Custom" installation is selected, you can;


- Install FANUC OPC Configurator only
- Change the installation folder.

				Title		FANUC OPC Server Operator's Manual	
				Draw		A-40622-00001EN	
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka				
04	2018.06.21	S.Matsukura	Data type added.				
03	2017.12.25	T.Hosaka	OPC UA support				
02	2016.01.13	T.Hosaka	Old CNC support and data type added.				
Ed.	Date	Design	Description				
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata
FANUC CORPORATION							Sheet. 19/167

- 1) Insert the installation media to the PC. The installer will automatically start.
If the installer does not start, please start the setup.exe in the installation media by using Windows Explorer.
When the following window appears, click the [Install] button. The required software is installed.



- 2) Click [Next] button.




						Title	FANUC OPC Server Operator's Manual			
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka							
04	2018.06.21	S.Matsukura	Data type added.							Draw
03	2017.12.25	T.Hosaka	OPC UA support							
02	2016.01.13	T.Hosaka	Old CNC support and data type added.							
Ed.	Date	Design	Description							FANUC CORPORATION
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata	Sheet.	20/167	

- 3) The license agreement window appears. Please read the agreement carefully. When you agree, click [I accept the terms in the licensee agreement], then click [Next] button.




										Title	FANUC OPC Server Operator's Manual		
										Draw	A-40622-00001EN		
05	2020.09.30	R.Imada	The security function of FOCAS2 added.	T.Hosaka									
04	2018.06.21	S.Matsukura	Data type added.										
03	2017.12.25	T.Hosaka	OPC UA support										
02	2016.01.13	T.Hosaka	Old CNC support and data type added.										
Ed.	Date	Design	Description				FANUC CORPORATION		Sheet.	21/167			
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata						

- 4) The customer information window appears. Enter your "User Name" and "Organization", then click [Next] button.



- 5) Setup Type selection window appears. Usually, select "Complete" and then click the [Next] button. The sequence proceeds to step 6.




In the following cases, select the "Custom" and then click the [Next] button.

- A) You install OPC Configurator only, and do not install OPC Server.
B) You change the folder to install the software.


						Title	FANUC OPC Server Operator's Manual			
						Draw	A-40622-00001EN			
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka							
04	2018.06.21	S.Matsukura	Data type added.							
03	2017.12.25	T.Hosaka	OPC UA support							
02	2016.01.13	T.Hosaka	Old CNC support and data type added.							
Ed.	Date	Design	Description			FANUC CORPORATION			Sheet.	22/167
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata			

Custom Setup window appears.




- A) If you do not install the FANUC OPC Server, click the icon of FANUC OPC Server, and then select [This feature will not be available].
- B) If you change the installation folder, click [Change...] button to change the folder to install the software.

6) If you click the [Install] button on the following window, the installation starts.



05	2020.09.30	R.Imada	The security function of FOCAS2 added.	T.Hosaka					
04	2018.06.21	S.Matsukura	Data type added.						
03	2017.12.25	T.Hosaka	OPC UA support						
02	2016.01.13	T.Hosaka	Old CNC support and data type added.						
Ed.	Date	Design	Description			FANUC CORPORATION		Sheet.	23/167
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata		

7) When the installation is completed, the following window appears.



The [FANUC OPC Configurator] icon is displayed on the desktop.




Click [Finish] button to end the installation.

1.4 Registration of serial number

Please register the serial number on the FANUC OPC Registration screen after you install the software.

- 1) To open the FANUC OPC Registration window, click [START], [PROGRAMS], [FANUC OPC Server] and then [FANUC OPC Registration].
- 2) The figure number for which the input of the serial number is necessary is displayed on the screen. Click the [OK] button.



							Title	FANUC OPC Server Operator's Manual	
							Draw	A-40622-00001EN	
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka						
04	2018.06.21	S.Matsukura	Data type added.						
03	2017.12.25	T.Hosaka	OPC UA support						
02	2016.01.13	T.Hosaka	Old CNC support and data type added.						
Ed.	Date	Design	Description				FANUC CORPORATION	Sheet.	24/167
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata		

3) Enter the serial number and then click the [Save] button.

4) Click the [OK] button when the confirmation message is displayed.


5) If the entered serial number is displayed on the screen, the registration is completed. Click the [End] button to exit the window.

									Title	FANUC OPC Server Operator's Manual			
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka						Draw	A-40622-00001EN			
04	2018.06.21	S.Matsukura	Data type added.										
03	2017.12.25	T.Hosaka	OPC UA support										
02	2016.01.13	T.Hosaka	Old CNC support and data type added.							FANUC CORPORATION		Sheet.	25/167
Ed.	Date	Design	Description										
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata						


1.5 Firewall Inbound Rules

At installation, it will be added FANUC OPC server rules to the Inbound rules of the Windows firewall. Rules at the time of installation, the profile to be applied has become only the [private]. In accordance with the personal computer of the network environment to be used, please add the profile that you want to use.

- 1) Open [Control Panel], Click [Windows Firewall], and then [Advanced Setting] Click.



- 2) Click the [Inbound Rules]. Select the "FANUC OPC Server" from the list of Inbound Rules, and then click Properties.




					Title	FANUC OPC Server Operator's Manual			
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka		Draw	A-40622-00001EN			
04	2018.06.21	S.Matsukura	Data type added.						
03	2017.12.25	T.Hosaka	OPC UA support						
02	2016.01.13	T.Hosaka	Old CNC support and data type added.		FANUC CORPORATION			Sheet.	26/167
Ed.	Date	Design	Description						
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata		

NOTE

Rules Please be set to both TCP and UDP.

- 3) Check the profile to be applied in the profile section of the Advanced Settings.




05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka							
04	2018.06.21	S.Matsukura	Data type added.							
03	2017.12.25	T.Hosaka	OPC UA support							
02	2016.01.13	T.Hosaka	Old CNC support and data type added.							
Ed.	Date	Design	Description		FANUC CORPORATION			Sheet.	27/167	
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata			

2

Un-installation

You can uninstall FANUC OPC Server from the [Programs and Features] in the [Control Panel] of Windows.



NOTE

Before you uninstall the software, please make sure that the FANUC OPC Server is not running. When it is running, please terminate it with the following steps. If the service mode is running, you do not need termination.

- 1) Please confirm whether an icon of OPC server is displayed in the system tray of Windows. The details of the procedure are described in "4.1 Display of OPC Server user interface" in "III. Configuration".
- 2) Please terminate the OPC Server when the icon is displayed.
 - Double click the icon to restore it to the normal size.
 - Click the [File] menu, and then click the [Force Server Exit] in the drop-down menu.


05	2020.09.30	R.Imada	The security function of FOCAS2 added.	T.Hosaka					
04	2018.06.21	S.Matsukura	Data type added.						
03	2017.12.25	T.Hosaka	OPC UA support						
02	2016.01.13	T.Hosaka	Old CNC support and data type added.						
Ed.	Date	Design	Description			FANUC CORPORATION		Sheet.	28/167
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata		

1

Quick guide

This chapter explains the necessary setting procedure of Ethernet communication and OPC Configurator to read and write PMC data of CNC from OPC Client.

The following system example is used in explanation.



1.1 Setting IP address of CNC

This section describes the setting procedure of IP address for CNC using the following example. As for the setting procedure of PC, please refer to the manual of Windows OS.

Equipment	IP ADDRESS
PC for OPC Server	192.168.1.1
CNC	192.168.1.213
SUBNET MASK	255.255.255.0
ROUTER IP ADDRESS	192.168.1.250


Port number used for the FOCAS2/Ethernet : 8193

NOTE

The above setting is an example. For details on IP addresses, subnet mask and router IP address, consult with the administrator of the network.


Setting of CNC

Below is the setting procedure of connecting Series 30i-B CNC to the PC with Embedded Ethernet. The setting procedure is different in each CNC. For details, please refer to the manual of each CNC.

- 1) Press function key .
- 2) Soft key [EMBED PORT] appears. When the soft key does not appear, press the continue key.
- 3) Enter the value "192.168.1.213" to [IP ADDRESS], "255.255.255.0" to [SUBNET MASK] and "192.168.1.250" to [ROUTER IP ADDRESS].


				Title	FANUC OPC Server Operator's Manual		
				Draw	A-40622-00001EN		
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka				
04	2018.06.21	S.Matsukura	Data type added.				
03	2017.12.25	T.Hosaka	OPC UA support				
02	2016.01.13	T.Hosaka	Old CNC support and data type added.				
Ed.	Date	Design	Description	FANUC CORPORATION		Sheet. 30/167	
Date	2015.09.25	Desig.	T.Hosaka				Check

- 4) Press soft key [FOCAS2]. Enter the value "8193" to [PORT NUMBER (TCP)], 0 to [PORT NUMBER (UDP)] and [TIME INTERVAL].



Verifying IP address setting

- 1) Click [START], [PROGRAMS], [ACCESSORIES], [COMMAND PROMPT] from the Windows menu.. Command prompt window appears.
- 2) Type "ping 192.168.1.213", and then press [ENTER] key. The connection will be tested four times. The response message "Reply from ..." shows a successful connection.



If the response message "Reply from..." is not received, confirm that the network switch and cables are connected appropriately and the IP addresses of CNC and PC are correct.

1.2 Setting of OPC Configurator

This section explains the setting procedure of OPC Configurator.

1.2.1 Creating a configuration file

The procedure to start OPC Configurator and create a setting file is as follows.

				Title	FANUC OPC Server Operator's Manual	
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka	Draw	A-40622-00001EN	
04	2018.06.21	S.Matsukura	Data type added.			
03	2017.12.25	T.Hosaka	OPC UA support			
02	2016.01.13	T.Hosaka	Old CNC support and data type added.	FANUC CORPORATION		Sheet. 31/167
Ed.	Date	Design	Description			
Date	2015.09.25	Desig.	T.Hosaka	Check	Apprv.	K.Murata

- 1) Double-Click the icon [FANUC OPC Configurator] on the desktop.



OPC Configurator starts.

- 2) Click the menu [FILE], [New Configuration].
- 3) Enter the file name "MyConfig1" in the item "Enter Configuration Name".
- 4) Click the [Done] button.
- 5) Click the menu [FILE], [Save Configuration].
- 6) Click the [Save] button in the default folder to save the configuration to the file "MyConfig1.fs2".

The default folder is as follows.


Windows 7 or later : C:\ProgramData\FANUC\OPCUI

Windows XP : C:\Documents and Settings\All Users\Application Data\FANUC\OPCUI

1.2.2 Settings about connecting CNC


The procedure to specify the settings about connecting CNC is as follows. There are items of Ethernet information, CNC type, the number of Path, and so on.

- 1) Right-click the icon [MyConfig1] in the OPC Explorer window.
- 2) Select [Add Machine] on the pop-up menu.




							Title	FANUC OPC Server Operator's Manual	
							Draw	A-40622-00001EN	
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka						
04	2018.06.21	S.Matsukura	Data type added.						
03	2017.12.25	T.Hosaka	OPC UA support						
02	2016.01.13	T.Hosaka	Old CNC support and data type added.						
Ed.	Date	Design	Description				FANUC CORPORATION	Sheet.	32/167
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata		

- 3) The Machine Configuration Wizard starts.
 In the following screens, it is necessary to input the value to the field where the mark "*" is displayed.
 Enter "TEST_30iB" in the "Machine Name" field. Click the [Next >>] button.




- 4) The Configure Ethernet Control tab appears.
 Enter "192.168.1.213" in the "IP Address" field, "8193" in "Port", "10" to "Timeout". If access code is set on Parameter No.10344 of CNC, enter same access code of CNC. If access code isn't set, not need to enter access code. Click the [Next >>] button.




				Title	FANUC OPC Server Operator's Manual	
				Draw	A-40622-00001EN	
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka			
04	2018.06.21	S.Matsukura	Data type added.			
03	2017.12.25	T.Hosaka	OPC UA support			
02	2016.01.13	T.Hosaka	Old CNC support and data type added.			
Ed.	Date	Design	Description	FANUC CORPORATION		Sheet. 33/167
Date	2015.09.25	Desig.	T.Hosaka			

- 5) The Control Information tab appears.
 Select the following value in the fields "Control Types", "PMC Paths", and "CNC Paths".
 Click the [Next >>] button.



- 6) The Path Naming tab appears.
 Enter "PATH_1" in the "Name" field. Select "M" in the "Mtype" field. Click the [Done] button.
 The settings are displayed in OPC Explorer.






1.2.3 Setting of Point

The procedure to specify the settings about point data is as follows.
 In this example, OPC Client reads/writes 2 bytes from R0000 of PMC with the unit of one byte.

						Title	FANUC OPC Server Operator's Manual		
						Draw	A-40622-00001EN		
05	2020.09.30	R.Imada	The security function of FOCAS2 added.	T.Hosaka					
04	2018.06.21	S.Matsukura	Data type added.						
03	2017.12.25	T.Hosaka	OPC UA support						
02	2016.01.13	T.Hosaka	Old CNC support and data type added.						
Ed.	Date	Design	Description			FANUC CORPORATION		Sheet.	34/167
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata		

- 1) Right-click the icon "TEST_30iB" in OPC Explorer window, and select [Add Point: TEST_30iB] on the pop-up menu. Point Configuration Wizard appears.



Click the [Next >>] button in Machine Selection tab.

						Title	FANUC OPC Server Operator's Manual			
05	2020.09.30	R.Imada				Draw	A-40622-00001EN			
04	2018.06.21	S.Matsukura								
03	2017.12.25	T.Hosaka								
02	2016.01.13	T.Hosaka				FANUC CORPORATION				
Ed.	Date	Design	Description						Sheet.	35/167
Date	2015.09.25	Desig.	T.Hosaka	Check	Apprv.				K.Murata	

3) The Path Selection tab appears.

Machine Selection Path Selection

When defining a data point, you must identify the path upon which the point will exist.

Provided below is a list of available paths for the machine you have selected.

Please select a path number for the point in order to continue through this wizard.

MyConfig1\TEST_30iB
PMC Path 1

Path for Data Point

PMC Path 1
CNC Path 1

<< Back Next >> Cancel

Select [PMC Path 1] and click the [Next >>] button.

					Title	FANUC OPC Server Operator's Manual							
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka							Draw	A-40622-00001EN		
04	2018.06.21	S.Matsukura	Data type added.										
03	2017.12.25	T.Hosaka	OPC UA support										
02	2016.01.13	T.Hosaka	Old CNC support and data type added.										
Ed.	Date	Design	Description								FANUC CORPORATION	Sheet.	36/167
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata						

- 4) The Data Type Selection tab appears.
 Select [PMC Byte] and click the [Next >>] button.

Machine Selection	Path Selection	Data Type Selection
<p>When defining a data point, you must identify the type of data the point reflects. Provided below is a list of available data types for the machine you have selected.</p> <p>Please select a point data type in order to continue through this wizard.</p> <p>MyConfig1\TEST_30iB PMC Path 1 Properties: PMC Byte - RW Point ID: [PMC1B_1] PMC Address Range: 0 - 0</p> <p>Select Data Type</p> <ul style="list-style-type: none"> PMC 2Byte PMC 4Byte PMC Alarm Messages PMC Alarm Number PMC Bit PMC Byte 		
<p><< Back Next >> Cancel</p>		

					Title	FANUC OPC Server Operator's Manual					
					Draw	A-40622-00001EN					
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka								
04	2018.06.21	S.Matsukura	Data type added.								
03	2017.12.25	T.Hosaka	OPC UA support								
02	2016.01.13	T.Hosaka	Old CNC support and data type added.								
Ed.	Date	Design	Description							FANUC CORPORATION	Sheet.
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata		37/167		

5) The Point Specifics tab appears.

Machine Selection Path Selection Data Type Selection **Point Specifics**

When defining a data point, you must identify specific information about that point. This information can include the memory location of the point, and the type of data the point reflects. Provided below are lists that will help define the specific point information you wish to collect. Please specify the locating information about your point in order to continue through this wizard.

MyConfig1\TEST_30iB
 PMC Path 1
 Properties: PMC Byte - RW
 Point ID: [PMC1B_1]
 PMC Address Range: 0 - 0

*** Writing to PMC addresses may result in unpredictable machine operation. See operators manual for detail.**

Point Return Type: UBYTE
 STRING

Point Access Type: R
 W
 RW

PMC Address Type: G
 F
 Y
 X
 A
 R
 T
 K
 C
 D

PMC Start Address: 0
 (0 - 59999)

Array Size: 1
 (1 - 60000)

<< Back Next >> Cancel

Select the items as follows and click the [Next >>] button.

Point Return Type: UBYTE
 STRING

Point Access Type: R
 W
 RW

PMC Address Type: R
 G
 F
 Y
 X
 A
 R
 T
 K
 C
 D

PMC Start Address: 0
 (0 - 59999)

Array Size: 2
 (1 - 60000)

						Title	FANUC OPC Server Operator's Manual		
05	2020.09.30	R.Imada		The security function of FOCAS2 added. T.Hosaka		Draw	A-40622-00001EN		
04	2018.06.21	S.Matsukura		Data type added.					
03	2017.12.25	T.Hosaka		OPC UA support					
02	2016.01.13	T.Hosaka		Old CNC support and data type added.		FANUC CORPORATION			
Ed.	Date	Design	Description						Sheet.
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata		

6) The Point Naming tab appears.

Machine Selection | Path Selection | Data Type Selection | Point Specifics | **Point Naming**

When defining a data point, you must identify specific information about that point. This information can include the memory location of the point, and the type of data the point reflects.

Provided below are lists that will help define the specific point information you wish to collect.

Please specify the locating information about your point in order to continue through this wizard.

MyConfig1\TEST_30iB
 PMC Path 1
 Properties: PMC Byte - UBYTE - RW - R
 PointID: [PMC1B_R_0_2]
 PMC Address Range: R 0 - R 1


Point Name

Point Description

<< Back Done Cancel

Enter "PMC_1B_R0000_02" in the "Point Name" field, and click the [Done] button.

7) Point Configuration Wizard is finished and the created point is displayed in OPC Explorer.



						Title	FANUC OPC Server Operator's Manual			
						Draw	A-40622-00001EN			
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka							
04	2018.06.21	S.Matsukura	Data type added.							
03	2017.12.25	T.Hosaka	OPC UA support							
02	2016.01.13	T.Hosaka	Old CNC support and data type added.							
Ed.	Date	Design	Description			FANUC CORPORATION			Sheet.	39/167
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata			

1.2.4 Saving the Configuration File


The procedure to save the settings to the file "MyConfig1.fs2" is as follows.

- 1) Click the menu [File], [Save Configuration]. The settings are saved in "MyConfig1.fs2".
Next, overwrite the configuration file to the file that OPC Server reads.
- 2) Click the menu [File], [Export].
- 3) Export Dialog appears. Please confirm that the export destination is the following folder.
- C:\ProgramData\FANUC\OPCServer
(In case of Windows XP, "C:\Documents and Settings\All Users\Application Data\FANUC\OPCServer")
- 4) If the folder is different, click the [Browser...] button. Browse For Folder dialog appears.
Select "C:\ProgramData\FANUC\OPCServer" folder, and then click the [OK] button.
(In case of Windows XP, select "C:\Documents and Settings\All Users\Application Data\FANUC\OPCServer" folder, and then click the [OK] button.)
- 5) Click the "OK" button, the Export Dialog window closes.

1.3 Confirming OPC Server Operation

The procedure to start the OPC Server is as follows.


- 1) After saving the configuration file by the procedure written in the previous section, click the "Server Status" tab. Status screen appears.



- 2) Click the menu [Tools], [Server], [Connect to Server].


						Title	FANUC OPC Server Operator's Manual					
						Draw	A-40622-00001EN					
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka									
04	2018.06.21	S.Matsukura	Data type added.									
03	2017.12.25	T.Hosaka	OPC UA support									
02	2016.01.13	T.Hosaka	Old CNC support and data type added.									
Ed.	Date	Design	Description							FANUC CORPORATION	Sheet.	40/167
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata					

3) Connect To Server window appears.



Confirm that [localhost] is displayed in the "Server PC Name / IP Address" field, and then click the [Connect] button.

The message, "Connection Successful", shows that the connection to the OPC Server succeeded.



Click the [Close] button to close the Connect To Server window.

1.4 Confirming OPC Client Operation

This chapter explains the procedure to confirm that OPC client can read and write R0000 area of PMC. In this section, the freeware OPC Client, "Software Toolbox OPC Quick Client (V4.86.108.0 - U)" (below OPC_QuickClient) is used as an example.

OPC_QuickClient can be downloaded from the home-page of Software Toolbox, Inc.


Home-page of Software Toolbox, Inc. : <http://www.softwaretoolbox.com>

Execute the downloaded SWTB_OPQuickClient.exe to install OPC_QuickClient.


The operating procedure of OPC_QuickClient is as follows.

- 1) Click the menu of Windows [All Programs], [Software Toolbox], [OPC Quick Client].
OPC_QuickClient appears.

								Title	FANUC OPC Server Operator's Manual		
								Draw	A-40622-00001EN		
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka								
04	2018.06.21	S.Matsukura	Data type added.								
03	2017.12.25	T.Hosaka	OPC UA support								
02	2016.01.13	T.Hosaka	Old CNC support and data type added.								
Ed.	Date	Design	Description					FANUC CORPORATION		Sheet.	41/167
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata				




- 2) Click the menu [Edit], [New Server Connection...].
- 3) The Server Properties window appears. Click [Local Machine], [FANUCOPC.SERVER.0]. And then, click the [OK] button.




						Title	FANUC OPC Server Operator's Manual					
						Draw	A-40622-00001EN					
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka									
04	2018.06.21	S.Matsukura	Data type added.									
03	2017.12.25	T.Hosaka	OPC UA support									
02	2016.01.13	T.Hosaka	Old CNC support and data type added.									
Ed.	Date	Design	Description							FANUC CORPORATION	Sheet.	42/167
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata					

4) Server Properties window is closed and [FANUCOPC.SERVER.0] is displayed on the left area of the main window. It means that the client is connected to OPC Server.



Right-click [FANUCOPC.SERVER.0]. Select [New Group...] on the drop-down menu.


6) The Group Properties window appears.



Enter "TEST_30iB" in the "Name" field. Click the [OK] button.


									Title	FANUC OPC Server Operator's Manual	
									Draw	A-40622-00001EN	
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka								
04	2018.06.21	S.Matsukura	Data type added.								
03	2017.12.25	T.Hosaka	OPC UA support								
02	2016.01.13	T.Hosaka	Old CNC support and data type added.								
Ed.	Date	Design	Description				FANUC CORPORATION			Sheet.	43/167
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata				

- 7) Group Properties window is closed, and added group [TEST_30iB] is displayed under [FANUCOPC.SERVER.0].




Right-click [TEST_30iB]. Click [New Item...] on the drop-down menu.

- 8) The Add Items window appears.




Double-click [FANUCOPC.SERVER.0]. Two items, [SVR] and [TEST_30iB] appear. Click [TEST_30iB]. Created point [PMC_1B_R0000_02] is displayed in the right area. Click this item, and then click [Add Leaves] button.

						Title	FANUC OPC Server Operator's Manual			
05	2020.09.30	R.Imada	The security function of FOCAS2 added.	T.Hosaka		Draw	A-40622-00001EN			
04	2018.06.21	S.Matsukura	Data type added.							
03	2017.12.25	T.Hosaka	OPC UA support							
02	2016.01.13	T.Hosaka	Old CNC support and data type added.				FANUC CORPORATION		Sheet.	44/167
Ed.	Date	Design	Description							
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata			



Click the [OK] button. Add Items window closes.

- 9) [PMC_1B_R0000_02] is displayed in [Item ID] of the Main windows. Its value is displayed in [Value].



If the value of R0000 equals 1 and R0001 equals 2, "[1, 2]" is displayed in [Value].

- 10) Save the settings. Click the menu [File], [Save As...].
 Save as dialog appears. Save the settings in any folder.
- 11) The saved settings can be read by Open dialog. To display the Open dialog, click the menu [File], [Open].
 After reading the configuration from the file, it is connected to the specified OPC Server automatically.

				Title		FANUC OPC Server Operator's Manual	
				Draw		A-40622-00001EN	
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka				
04	2018.06.21	S.Matsukura	Data type added.				
03	2017.12.25	T.Hosaka	OPC UA support				
02	2016.01.13	T.Hosaka	Old CNC support and data type added.				
Ed.	Date	Design	Description				
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata
FANUC CORPORATION						Sheet.	45/167

2

Management of the configuration data

FANUC OPC Server reads the settings from the configuration file for operation, and it works according to the contents of it.

The folder and file name of the configuration file for operation are fixed.

OS	Configuration file for operation
Windows XP	C:\Documents and Settings\All Users\Application Data\FANUC\OPCServer\FASOPC.fs2
Windows 7 or later	C:\ProgramData\FANUC\OPCServer\FASOPC.fs2


FANUC OPC Configurator can preserve the created setting data in an arbitrary folder by an arbitrary name. The default folder to preserve the setting data is the following places.

OS	Default folder to preserve the setting data
Windows XP	C:\Documents and Settings\All Users\Application Data\FANUC\OPCUI
Windows 7 or later	C:\ProgramData\FANUC\OPCUI

The configuration data currently opened by the FANUC OPC Configurator can be overwritten to the configuration file for operation by "Export" procedure. As a result, the setting of the OPC Server can be changed.

The name of the file created by the "Export" procedure is fixed as "FASOPC.fs2". The folder of it can be specified.

If OPC Server and OPC Configurator run on the same PC, please specify the folder of the configuration file for operation in "Export" procedure. Then, the configuration of the OPC Server can be changed.



Ed.	Date	Design	Description	Title			
				FANUC OPC Server Operator's Manual			
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka	Draw	A-40622-00001EN		
04	2018.06.21	S.Matsukura	Data type added.				
03	2017.12.25	T.Hosaka	OPC UA support				
02	2016.01.13	T.Hosaka	Old CNC support and data type added.				
FANUC CORPORATION		Sheet.	46/167				
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata

3

OPC Configurator

This chapter explains the details of OPC Configurator, the setting tool of OPC Server.

Notes on using the functions for the first time

⚠ WARNING

Before using the OPC Server, fully understand the instructions written in "GENERAL WARNINGS FOR CNC APPLICATION DEVELOPMENT" in "SAFETY PRECAUTIONS" at the beginning of this manual.
If you start operation before fully understanding them, the machine may behave unexpectedly, possibly causing damage to the tool, machine, and/or workpiece, or injury to the user.

⚠ CAUTION

Before performing communication using the OPC Server for the first time, consult with your network administrator, carefully set a network address and other items, and conduct communication tests thoroughly. Any error in settings such as a network address setting can lead to an adverse influence such as a communication failure on the entire network. Be very careful about any communication failure. The load on the network may become greater than expected depending on the performance of the personal computer. Before using the functions, completely confirm that there is no problem with the entire system including communication with the personal computer.

⚠ CAUTION

- 1 In the PMC area, the R area, and E area in volatile memory are all set to 0 immediately after power-on.
- 2 The E area in the PMC area is normally allocated to volatile memory. However, it can also be used as nonvolatile memory by setting the option.
When the area is used as nonvolatile memory, the contents of the area are retained even after the power is turned off. So, special attention should be paid not to cause an unpredictable operation when the power is turned on next time.

3.1 Starting and quitting

Starting

Click the [FANUC OPC Configurator] icon on the desktop.

Or click [START], [PROGRAMS], [FANUC OPC Server], [FANUC OPC Configurator] on the windows menu.


Quitting

Click the upper right [x] button, or click the menu [File], [Exit].

						Title	FANUC OPC Server Operator's Manual		
05	2020.09.30	R.Imada	The security function of FOCAS2 added.	T.Hosaka		Draw	A-40622-00001EN		
04	2018.06.21	S.Matsukura	Data type added.						
03	2017.12.25	T.Hosaka	OPC UA support						
02	2016.01.13	T.Hosaka	Old CNC support and data type added.						
Ed.	Date	Design	Description			FANUC CORPORATION		Sheet.	48/167
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata		

3.2 Screen structure

OPC Configurator consists of four screens, Data View、Server Status、OPC Explorer and Property View.



The views are dockable and can be arranged to the users liking by dragging them within the parent form. The Data View, Server Status, and Property View may be also float outside of the parent form. The procedure to restore the size and place to the default settings is as follows.


- 1) Click [TOOLS] on the top menu.
- 2) Click [DEFAULTS], [Reset All Views] on drop-down menu.

Followings are the explanation about the operation.

					Title	FANUC OPC Server Operator's Manual			
05	2020.09.30	R.Imada	The security function of FOCAS2 added.	T.Hosaka	Draw	A-40622-00001EN			
04	2018.06.21	S.Matsukura	Data type added.						
03	2017.12.25	T.Hosaka	OPC UA support						
02	2016.01.13	T.Hosaka	Old CNC support and data type added.						
Ed.	Date	Design	Description		FANUC CORPORATION			Sheet.	49/167
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata		

3.3 OPC Explorer

OPC explorer view provides a tree view of the configured machines and points.



Possible operation in OPC Explorer is as follows.

3.3.1 Add Element

The function of the Add Element button [+] is dependent on what is currently selected in the OPC Explorer view.

- When the OPC Explorer view is blank, the system will assume you want to create a new configuration.
- If the configuration file is currently selected, the system assumes you want add a new machine.
- If a machine is selected, the system assumes you want to add a new point for that machine.

3.3.2 Delete Element

The element that will be deleted by the Delete Element button [🗑] is dependent on what is currently selected in the window.

MACHINES, CNC PATHS, and POINTS may be deleted.

Entire configurations may not be deleted.

When CNC/PMC PATH is deleted, all points under the selected CNC/PMC PATH are deleted.

3.3.3 Refresh

The Refresh View button [🔄] initiates a manual refresh of the OPC Explorer view. If a new element has been added the view will automatically refresh.

3.3.4 Expand Tree

The Expand Tree button [+] fully expands the tree view to expose all machines, paths, and point currently configured in the active server configuration.

Clicking the + button to the left of any element will expand the tree to reveal all of the related sub-elements.

3.3.5 Collapse Tree

The Collapse Tree button [-] fully collapses the tree view to expose only the root configuration.

05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka			Title	FANUC OPC Server Operator's Manual			
04	2018.06.21	S.Matsukura	Data type added.			Draw	A-40622-00001EN			
03	2017.12.25	T.Hosaka	OPC UA support							
02	2016.01.13	T.Hosaka	Old CNC support and data type added.							
Ed.	Date	Design	Description			FANUC CORPORATION			Sheet.	50/167
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata			

Clicking the  button to the left of any element will collapse only of the relative sub-elements.

3.4 Property View


This window shows detail about the element that is currently selected in the OPC Explorer view.

Property View	
TEST_30iB	
ID	48
Machine Name	TEST_30iB
Machine IP Address	192.168.1.213
Machine Port	8193
Timeout (1-60 Seconds)	10
Group ID	1
Description	
PMC Paths	1
CNC Paths	1
CNC Type	30i
Active Machine	True

3.4.1 Next Button


The Next button [] advances to the next item in the OPC Explorer view relative to the currently selected item. The details of the selected element are displayed in the Property View.

3.4.2 Previous Button

The Previous button [] advances to the previous item in the OPC Explorer view relative to the currently selected item. The details of the selected element are displayed in the Property View.

3.5 Data View


The Data View tab displays detail of the configured points under the machine, CNC Path, PMC path. Double-click the nodes to view the details of the configured sub-elements.



				Title	FANUC OPC Server Operator's Manual			
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka	Draw	A-40622-00001EN			
04	2018.06.21	S.Matsukura	Data type added.					
03	2017.12.25	T.Hosaka	OPC UA support					
02	2016.01.13	T.Hosaka	Old CNC support and data type added.	FANUC CORPORATION			Sheet.	51/167
Ed.	Date	Design	Description					
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata	

3.6 Server Status

The server status tab provides information to the user about the operation of the OPC server.



Server : Connected

Connected Server: localhost FANUCOPC.SERVER.0

SVR.STAT_SAMPLE_PERIOD	1000
SVR.STAT_NUM_CLIENTS	1
SVR.STAT_NUM_GROUPS	1
SVR.STAT_NUM_ITEMS	18
SVR.STAT_NUM_READS_PER_PD	0
SVR.STAT_NUM_WRITES_PER_PD	0
SVR.STAT_NUM_CHG_PER_PD	0
SVR.OUTPUTQUEUECOUNT	0
SVR.LASTREADTIME	0
SVR.LICENSE_EXPIRATION	12/31/9999
SVR.LICENSE_APPLIED_TO	0
SVR.LICENSE_USERS_ALLOWED	10
SVR.LICENSE_NUMBER_OF_MACHINES_ALLOWED	100
SVR.NUMBER_OF_ACTIVE_MACHINES	0
SVR.LICENSE_STATUS	Licensed
SVR.TOTAL_NUMBER_OF_MACHINES	0
SVR.SERVER_VERSION	2.0.0.0
SVR.NUMBER_OF_LOADED_MACHINES	0

To view the FANUC OPC server status information, the server must be connected.

Please connect to the OPC Server with the procedure described in "1.3 Confirming OPC Server Operation" of "III. CONFIGURATION".

					Title	FANUC OPC Server Operator's Manual		
05	2020.09.30	R.Imada	The security function of FOCAS2 added.	T.Hosaka	Draw	A-40622-00001EN		
04	2018.06.21	S.Matsukura	Data type added.					
03	2017.12.25	T.Hosaka	OPC UA support					
02	2016.01.13	T.Hosaka	Old CNC support and data type added.					
Ed.	Date	Design	Description			FANUC CORPORATION	Sheet.	52/167
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata	

3.7 Configuration Settings

These settings will be used for the OPC Server to control the update rate and log file creation.

- 1) Click [FILE] on the top menu, and click [New Configuration] on the drop-down menu.
- 2) Enter <YOUR CONFIG NAME> in the "ENTER CONFIGURATION NAME" field.
- 3) The following characters cannot be used for the Configuration Name.

¥ / : * ? " < > |

The procedure to display this screen for the existing configuration file is as follows.

- 1) Right click Configuration file displayed at the root tree of the OPC Explorer, click [Edit: <Configuration Name>] on the drop-down menu.

When this screen is opened for the existing configuration file, the value of "ENTER CONFIGURATION NAME" field is read-only. The value cannot be changed.

Configuration Settings

Enter Configuration Name: MyConfig1

Server Settings

Minimum Client Update Time: 1000 mSecs

Read Write Device Timeout: 10 Sec

Shutdown Server When Last Client Disconnects Security Private

Log File Settings

Log File Open Time: 90 Min

Log File Maximum Lifetime: 14 Days

Log File Level: 4

Done Cancel

3.7.1 Minimum Client Update Time

This sets the minimum update time of the value passed to the client.

The client software you choose to use will also have an update time setting. This setting is the master of the two, so if this setting is 1000mSec and the client is set to 100mSec, the client setting will be overridden to 1,000mSec.

This value is set in units of milliseconds and the default value is 1,000ms. Setting range is 10 to 60,000. When the value from 10 to 99 is entered, it is regarded as 100, and when the value larger than 60,000 is entered, it is regarded as 60,000.

3.7.2 Read Write Device Timeout

This sets the maximum allowable time from when the server sends the request to the CNC until the response returns back from the CNC. If the round-trip time is greater than this setting, a CNC connection time-out occurs. This value is set in units of seconds, default is 10 seconds. Setting range is 0~32,767.

					Title	FANUC OPC Server Operator's Manual	
					Draw	A-40622-00001EN	
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka				
04	2018.06.21	S.Matsukura	Data type added.				
03	2017.12.25	T.Hosaka	OPC UA support				
02	2016.01.13	T.Hosaka	Old CNC support and data type added.				
Ed.	Date	Design	Description			FANUC CORPORATION	
Date	2015.09.25	Desig.	T.Hosaka	Check	Apprv.	K.Murata	Sheet. 53/167

3.7.3 OPC UA Mode

Select the mode of operation of the OPC server.

Check box is enabled : OPC server runs on OPC UA standard.

Check box is disabled : OPC server runs on OPC Classic of DA standard.

3.7.4 Shutdown Server When Last Client Disconnects

This checkbox flags the OPC server to shut down when it detects no clients are connected.

Regardless of this setting, the server will automatically start when any client requests a connection.

If the OPC UA mode is checked, this check box is automatically disabled.

3.7.5 Log File Open Time

This sets the maximum amount of time the current server log file will be used. At the end of this period a new log file will be created and the old file will remain in the LOGS directory folder.

This value is set in units of minute, default is 90 minutes. Setting range is 0~2,147,483,647.

3.7.6 Log File Maximum Lifetime

This sets how long the log file will remain in the server LOGS directory folder.

This value is set in units of days, default is 14 days.

Any log files that remain in the folder longer than the period that is specified with this setting will be automatically deleted from the folder.

Setting range is 0 to 32,767.

The LOGS directory folder is as follows.

- Windows 7 or later : C:\ProgramData\FANUC\OPCServer\Logs
- Windows XP : C:\Documents and Settings\All Users\Application Data\FANUC\OPCServer\Logs

3.7.7 Log File Level

This setting determines how detailed the server log messages will be.

Log level 1 is the least amount of logging and is used for typical day to day operations.

Log level 5 is the most detailed logging level and is used when troubleshooting a connection or server problem.

3.8 Machine Configuration Wizard


This wizard steps through the process of adding a new machine to the configuration file.

1) There are three ways to invoke the machine configuration wizard...


- Main menu : [Tools], [Wizard], [Machine Configuration]
- OPC Explorer : RIGHT-CLICK configuration and select [Add Machine]
- OPC Explorer : CLICK [+] toolbar button with the configuration pre-selected

				Title	FANUC OPC Server Operator's Manual			
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka	Draw	A-40622-00001EN			
04	2018.06.21	S.Matsukura	Data type added.					
03	2017.12.25	T.Hosaka	OPC UA support					
02	2016.01.13	T.Hosaka	Old CNC support and data type added.					
Ed.	Date	Design	Description	FANUC CORPORATION			Sheet.	54/167
Date	2015.09.25	Desig.	T.Hosaka					

- 2) The Select Connection Type tab appears in the wizard.



- 3) Enter the "Machine Name", which can be any name the user wants. This will be the primary node name displayed in explorer view. The character that can be used is an alphanumeric character, under bar, and hyphen.
- 4) Enter the "Machine Description", this will appear in the property view window. Click the [Next>>] button to advance to the next tab.
- 5) The Configure Ethernet Control tab appears in the wizard.




- 6) Enter the "IP Address", which is specified at [COMMON] screen of CNC.
- 7) Enter the "Port", which is specified in "PORT NUMBER (TCP)" at [FOCAS2] screen of CNC.
- 8) Enter the "Timeout", this is the allowable amount of inactivity, in seconds.
- 9) Enter the "Access code", which is same access code on CNC.
 If access code is set on CNC (Parameter of CNC No.10344 ≠ 0), check this check box and enter the same value as the access code set on CNC.
 If access code is not set on CNC (Parameter of CNC No.10344 = 0) or FOCAS2 security function is not supported on CNC, do not check this check box.

For details about overview of FOCAS2 security function and supported version of CNC, refer to following technical report.
 TMN20/097 About a security function in FOCAS2 Library (A-42146-00166EN)

Click the [Next>>] button to advance to the next tab.


						Title	FANUC OPC Server Operator's Manual		
						Draw	A-40622-00001EN		
05	2020.09.30	R.Imada							
04	2018.06.21	S.Matsukura							
03	2017.12.25	T.Hosaka							
02	2016.01.13	T.Hosaka							
Ed.	Date	Design	Description				FANUC CORPORATION	Sheet.	55/167
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata		

10) The Control Information tab appears in the wizard.




- 11) Select the "Control Types", series and model in the drop-down box.
 - 12) Select the "Machine Type" for the CNC Control from [M] or [T]. When [30i], [31i], [32i] or [35i] is selected at "Control Types", "Machine Type" cannot be selected.
 - 13) Select the "PMC Paths", the number of PMC Path.
 - 14) Select the "CNC Paths", the number of CNC Path.
- Click the [Next>>] button to advance to the next tab.

15) The Path Naming tab appears in the wizard.



- 16) Enter the name of CNC Path in the "Name" field. This value is displayed at the CNC Path in CNC Explorer, and the item "Description" in Property View.
- 17) Select the "Machine Type" for the CNC Path from [M] or [T]. When [0iD], [0iF], [PMiA] ,[PMiH] or [PMiD] is selected at "Control Types" in Control Information tab, "Machine Type" cannot be selected.
- 18) Click [Done] to complete the wizard.
The added machine now appears in OPC Explorer view, and if selected by a mouse click the details that have just been entered appear in the Property View.
- 19) Right-Click "Machine Name" in explorer, and select "Edit <Machine Name>" on the pop-up menu. This will start the wizard again so you can make changes to the machine configuration if desired.

							Title	FANUC OPC Server Operator's Manual	
05	2020.09.30	R.Imada	The security function of FOCAS2 added.	T.Hosaka			Draw	A-40622-00001EN	
04	2018.06.21	S.Matsukura	Data type added.						
03	2017.12.25	T.Hosaka	OPC UA support						
02	2016.01.13	T.Hosaka	Old CNC support and data type added.				FANUC CORPORATION	Sheet.	56/167
Ed.	Date	Design	Description						
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.			



For the procedure after this, please refer to the section corresponding to the point type you create.

- 3.9.1 CNC System Information Point
- 3.9.2 Tool Offsets Point
- 3.9.3 Work Offsets Point
- 3.9.4 Program Data Point
- 3.9.5 Custom Macro Variable Point
- 3.9.6 Alarm Information Point
- 3.9.7 Axis Name Point
- 3.9.8 Position Information Point
- 3.9.9 PMC Data Point
- 3.9.10 PMC Alarm Point
- 3.9.11 Number of Machined Parts
- 3.9.12 P-CODE Variable Point
- 3.9.13 Operator Messages Point
- 3.9.14 CNC Status Point

NOTE

Even if points are defined as an array in the FANUC OPC server, it is not possible to read from and write to the specified range by using IndexRange from the OPC UA client.

						Title	FANUC OPC Server Operator's Manual		
						Draw	A-40622-00001EN		
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka						
04	2018.06.21	S.Matsukura	Data type added.						
03	2017.12.25	T.Hosaka	OPC UA support						
02	2016.01.13	T.Hosaka	Old CNC support and data type added.						
Ed.	Date	Design	Description			FANUC CORPORATION		Sheet.	58/167
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata		

3.9.1 CNC System Information Point

CNC model information can be read. This is a read-only point.

Data Type	Example
CNC Series	30, 16, PM
CNC Type	M, T, MM
CNC controlled Axis Count/Path	3, 7

- 1) Start the Point Configuration Wizard. Click the [Next >>] button. The Path Selection tab appears in the wizard.
- 2) Select [CNC Path 1] in the path for data point list box. Click the [Next >>] button.

					Title	FANUC OPC Server Operator's Manual
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka		Draw	A-40622-00001EN
04	2018.06.21	S.Matsukura	Data type added.			
03	2017.12.25	T.Hosaka	OPC UA support			
02	2016.01.13	T.Hosaka	Old CNC support and data type added.			
Ed.	Date	Design	Description		FANUC CORPORATION	
Date	2015.09.25	Desig.	T.Hosaka	Check		
					Sheet.	59/167

- 3) The Data Type Selection tab appears in the wizard.
Select the data type in the Select Data Type list box. Click the [Next >>] button.

Machine Selection Path Selection **Data Type Selection**

When defining a data point, you must identify the type of data the point reflects. Provided below is a list of available data types for the machine you have selected.

Please select a point data type in order to continue through this wizard.

MyConfig1\TEST_30iB
CNC Path 1
Properties: CNC Series - STRING - R
Point ID: [CNCS_1]

Select Data Type

- Active Program Number
- Alarm Messages
- Alarm Number
- Axis Name
- CNC controlled Axis Count/Path**
- CNC Series**
- CNC Type**
- Custom Macro Common Variable(#100-#199)
- Custom Macro Common Variable(#500-#999)
- Custom Macro Common Variable(#98000-#98499)
- Custom Macro Embedded Macro Variable(#200-#499)
- Custom Macro Local Variable(#1-#33)
- Custom Macro System Variable(#1000-)
- Custom Macro System Variable(#10000-)
- Custom Macro System Variable(#100000-)
- Distance to go Position

- 4) The Point Specifics tab appears in the wizard.
If you select the "CNC series" or "CNC type", Point Return Type is "STRING" only.
Click the [Next >>] button.

Machine Selection Path Selection Data Type Selection **Point Specifics**

When defining a data point, you must identify specific information about that point. This information can include the memory location of the point, and the type of data the point reflects. Provided below are lists that will help define the specific point information you wish to collect. Please specify the locating information about your point in order to continue through this wizard.

MyConfig1\TEST_30iB.CNC_1
CNC Path 1
Properties: CNC controlled Axis Count/Path - STRING - R
Point ID: [CNCAXT_1]

Point Return Type

- INT16
- STRING**

Point Access Type

- R**

						Title	FANUC OPC Server Operator's Manual		
						Draw	A-40622-00001EN		
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka						
04	2018.06.21	S.Matsukura	Data type added.						
03	2017.12.25	T.Hosaka	OPC UA support						
02	2016.01.13	T.Hosaka	Old CNC support and data type added.			FANUC CORPORATION			
Ed.	Date	Design	Description						Sheet.
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata		

5) The Point Naming tab appears in the wizard.

Machine Selection	Path Selection	Data Type Selection	Point Specifics	Point Naming
<p>When defining a data point, you must identify specific information about that point. This information can include the memory location of the point, and the type of data the point reflects.</p> <p>Provided below are lists that will help define the specific point information you wish to collect.</p> <p>Please specify the locating information about your point in order to continue through this wizard.</p> <p>MyConfig1\TEST_30iB.CNC_1 CNC Path 1 Properties: CNC Series - STRING - R PointName: CNC_1 PointID: [CNCS_1]</p> <p>Point Name <input type="text" value="CNC_1"/> New Point being created</p> <p>Point Description <input type="text"/></p>				

Enter point name in the "Point Name" field. Enter point description in the "Point Description" field. Click the [Done] button, the point should now appear in the OPC Explorer view.

					Title	FANUC OPC Server Operator's Manual	
					Draw	A-40622-00001EN	
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka				
04	2018.06.21	S.Matsukura	Data type added.				
03	2017.12.25	T.Hosaka	OPC UA support				
02	2016.01.13	T.Hosaka	Old CNC support and data type added.				
Ed.	Date	Design	Description		FANUC CORPORATION		
Date	2015.09.25	Desig.	T.Hosaka	Check	Apprv.	K.Murata	Sheet. 61/167

3.9.2 Tool Offsets Point


Tool Offsets status can be read or written.

- 1) Start the Point Configuration Wizard. Click the [Next >>] button. The Path Selection tab appears in the wizard.
- 2) Select [CNC Path 1] in the path for data point list box. Click the [Next >>] button.

Machine Selection	Path Selection		
<p>When defining a data point, you must identify the path upon which the point will exist.</p> <p>Provided below is a list of available paths for the machine you have selected.</p> <p>Please select a path number for the point in order to continue through this wizard.</p> <p>MyConfig1\TEST_30iB CNC Path 1</p>			
<p>Path for Data Point</p> <table border="1"> <tr> <td>PMC Path 1</td> </tr> <tr> <td>CNC Path 1</td> </tr> </table>		PMC Path 1	CNC Path 1
PMC Path 1			
CNC Path 1			


						Title	FANUC OPC Server Operator's Manual			
						Draw	A-40622-00001EN			
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka							
04	2018.06.21	S.Matsukura	Data type added.							
03	2017.12.25	T.Hosaka	OPC UA support							
02	2016.01.13	T.Hosaka	Old CNC support and data type added.			FANUC CORPORATION			Sheet.	62/167
Ed.	Date	Design	Description							
Date	2015.09.25	Desig.	T.Hosaka	Check						

- 3) The Data Type Selection tab appears in the wizard.
 Select [Tool Offsets] in the Select Data Type list box. Click the [Next >>] button.



05	2020.09.30	R.Imada	The security function of FOCAS2 added.	T.Hosaka						
04	2018.06.21	S.Matsukura	Data type added.							
03	2017.12.25	T.Hosaka	OPC UA support							
02	2016.01.13	T.Hosaka	Old CNC support and data type added.							
Ed.	Date	Design	Description				FANUC CORPORATION		Sheet.	63/167
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata			

4) The Point Specifics tab appears in the wizard.



Select [R]:read-only, [W]:write only or [RW]:read/write at "Point Access Type".
 Select the "Offset Number" and "Offset Type". Please refer to the following offset type list for details.
 Click the [Next >>] button.

Offset Type list

The items displayed in Offset Type depend on the Control Types and Machine Type specified in the machine configuration wizard. There is an item that cannot be used even if it is displayed in the offset type list according to the option setting of CNC. When invalid offset type is specified, the client cannot read/write the value of such item.

In case of M system of 30i/31i/32i-A/B, 35i-B, 0i-F

Offset Type	Memory A	Memory B (*1)	Memory C
Cutter Radius - Wear	DATA	WEAR	WEAR(RADIUS)
Cutter Radius - Geometry	Not used	GEOM	GEOM(RADIUS)
Tool Length - Wear	Not used	Not used	WEAR(LENGTH)
Tool Length - Geometry	Not used	Not used	GEOM(LENGTH)
Imaginary Tool Nose - Wear	T(*2)	T(*2)	T(*2)
Imaginary Tool Nose - Geometry	T(*2)	T(*2)	T(*2)
Corner R - Wear	Not used	Not used	WEAR(CNR R)(*2)
Corner R - Geometry	Not used	Not used	GEOM(CNR R)(*2)

*1 0i-F does not support Memory B.

*2 Tool radius - Tool nose radius compensation is required.

									Title	FANUC OPC Server Operator's Manual
									Draw	A-40622-00001EN
05	2020.09.30	R.Imada	The security function of FOCAS2 added.	T.Hosaka						
04	2018.06.21	S.Matsukura	Data type added.							
03	2017.12.25	T.Hosaka	OPC UA support							
02	2016.01.13	T.Hosaka	Old CNC support and data type added.							
Ed.	Date	Design	Description					FANUC CORPORATION	Sheet.	64/167
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata			

In case of Mc system of 30i/31i/32i-A/B (With Tool offset for Milling and Turning function option)

Offset Type	Memory C(*1)
X Axis - Wear	X W
X Axis - Geometry	X G
Tool Length - Wear	Z/LENGTH W
Tool Length - Geometry	Z/LENGTH G
Cutter Radius -Wear	NOSE R/RAD W
Cutter Radius - Geometry	NOSE R/RAD G
Imaginary Tool Nose - Wear	T
Imaginary Tool Nose - Geometry	T
Y Axis - Wear	Y W
Y Axis - Geometry	Y G
Corner R - Wear	CORNER R W
Corner R - Geometry	CORNER R G

*1 Tool offset memory C is required.

In case of Tc system of 30i/31i/32i-A/B (With Tool offset for Milling and Turning function option)

Offset Type	Memory C(*1)
X Axis - Wear	X W
X Axis - Geometry	X G
Z Axis - Wear	Z/LENGTH W
Z Axis - Geometry	Z/LENGTH G
Nose R - Wear	NOSE R/RAD W
Nose R - Geometry	NOSE R/RAD G
Imaginary Tool Nose - Wear	T
Imaginary Tool Nose - Geometry	T
Y Axis - Wear	Y W
Y Axis - Geometry	Y G
X Axis - 2nd Geometry Offset-Geometry	X AXIS G 2ND GEOM
Z Axis - 2nd Geometry Offset-Geometry	Z AXIS G 2ND GEOM
Y Axis - 2nd Geometry Offset-Geometry	Y AXIS G 2ND GEOM

*1 Tool offset memory C is required.

In case of M system of 0i-B/C, 0i-D, 16i/18i/21i-A/B, PMi-D/H, PMi-A

Offset Type	Memory A	Memory B (*1)	Memory C
Cutter Radius - Wear	DATA	WEAR	WEAR(RADIUS)
Cutter Radius - Geometry	Not used	GEOM	GEOM(RADIUS)
Tool Length - Wear	Not used	Not used	WEAR(LENGTH)
Tool Length - Geometry	Not used	Not used	GEOM(LENGTH)

*1 0i-B/C and 0i-D do not support memory B.

				Title	FANUC OPC Server Operator's Manual		
					Draw	A-40622-00001EN	
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka				
04	2018.06.21	S.Matsukura	Data type added.				
03	2017.12.25	T.Hosaka	OPC UA support				
02	2016.01.13	T.Hosaka	Old CNC support and data type added.				
Ed.	Date	Design	Description	FANUC CORPORATION		Sheet.	65/167
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata

In case of T system of 30i/31i/32i-A/B,0i-F

Offset Type	None Tool geometry/wear compensation	Add Tool geometry/wear compensation
X Axis - Wear	X	X W
X Axis - Geometry	Not used	X G
Z Axis - Wear	Z	Z W
Z Axis - Geometry	Not used	Z G
Nose R - Wear	R (*1)	R W(*1)
Nose R - Geometry	Not used	R G(*1)
Imaginary Tool Nose - Wear	T (*1)	T W(*1)
Imaginary Tool Nose - Geometry	Not used	T G(*1)
Y Axis - Wear	Y AXIS (*2)	Y AXIS W(*2)
Y Axis - Geometry	Not used	Y AXIS G(*2)
X Axis - 2nd Coord Wear	X OFFSET-2(*3)	X W WEAR-2(*3)
X Axis - 2nd Coord Geometry	Not used	X G GEOMETRY-2(*3)
Z Axis - 2nd Coord Wear	Z OFFSET-2(*3)	Z W WEAR -2(*3)
Z Axis - 2nd Coord Geometry	Not used	Z G GEOMETRY -2(*3)
Nose R - 2nd Coord Wear	R OFFSET-2(*3)	R W WEAR -2(*3)
Nose R - 2nd Coord Geometry	Not used	R G GEOMETRY -2(*3)
Imaginary Tool Nose - 2nd Coord Wear	T OFFSET-2(*3)	T W WEAR -2(*3)
Imaginary Tool Nose - 2nd Coord Geometry	Not used	T G GEOMETRY -2(*3)
Y Axis - 2nd Coord Wear	Y AXIS OFFSET-2(*2, *3)	Y AXIS W OFFSET-2(*2, *3)
Y Axis - 2nd Coord Geometry	Not used	Y AXIS G OFFSET-2(*2, *3)
4th Axis - Wear	E AXIS (*4)	E AXIS W(*4)
4th Axis - Geometry	Not used	E AXIS G(*4)
5th Axis - Wear	5 AXIS (*4)	5 AXIS W(*4)
5th Axis - Geometry	Not used	5 AXIS G(*4)
X Axis - 2nd Geometry Offset - Geometry	Not used	X AXIS G 2ND GEON(*5)
Z Axis - 2nd Geometry Offset - Geometry	Not used	Z AXIS G 2ND GEON(*5)
Y Axis - 2nd Geometry Offset - Geometry	Not used	Y AXIS G 2ND GEON(*2, *5)
X Axis - 2nd Geometry Offset - 2nd Coord Geometry	Not used	X AXIS G 2ND GEON-2(*3, *5)
Z Axis - 2nd Geometry Offset - 2nd Coord Geometry	Not used	Z AXIS G 2ND GEON -2(*3, *5)
Y Axis - 2nd Geometry Offset - 2nd Coord Geometry	Not used	Y AXIS G 2ND GEON -2(*2, *3, *5)

*1 Tool radius - Tool nose radius compensation is required.

*2 Y-axis offset is required.

*3 The offset memory switching function is required.

*4 4th/5th Axis Offset is required.

*5 2nd Geometry Tool Offset is required.

						Title	FANUC OPC Server Operator's Manual	
						Draw	A-40622-00001EN	
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka					
04	2018.06.21	S.Matsukura	Data type added.					
03	2017.12.25	T.Hosaka	OPC UA support					
02	2016.01.13	T.Hosaka	Old CNC support and data type added.			FANUC CORPORATION		Sheet. 66/167
Ed.	Date	Design	Description					
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata	

In case of T system of 0i-B/C,0i-D,16i/18i/21i-A/B

Offset Type	None Tool geometry/wear compensation	Add Tool geometry/wear compensation
X Axis - Wear	X	X W
X Axis - Geometry	Not used	X G
Z Axis - Wear	Z	Z W
Z Axis - Geometry	Not used	Z G
Nose R - Wear	R (*1)	R W(*1)
Nose R - Geometry	Not used	R G(*1)
Imaginary Tool Nose - Wear	T (*1)	T W(*1)
Imaginary Tool Nose - Geometry	Not used	T G(*1)
Y Axis - Wear	Y AXIS (*2)	Y AXIS W(*2)
Y Axis - Geometry	Not used	Y AXIS G(*2)

*1 Tool nose radius compensation is required.

*2 Y-axis offset is required.

5) The Point Naming tab appears in the wizard.

Machine Selection	Path Selection	Data Type Selection	Point Specifics	Point Naming
<p>When defining a data point, you must identify specific information about that point. This information can include the memory location of the point, and the type of data the point reflects.</p> <p>Provided below are lists that will help define the specific point information you wish to collect.</p> <p>Please specify the locating information about your point in order to continue through this wizard.</p> <p>MyConfig1\TEST_30iB.TOOL_1_RAD CNC Path 1 Properties: Tool Offsets - STRING - R - 1 Point Name: TOOL_1_RAD Point ID: [TOFS_1_0_1]</p> <p>Point Name <input type="text" value="TOOL_1_RAD"/> New Point being created</p> <p>Point Description <input type="text"/></p>				


Enter point name in the "Point Name" field. Enter point description in the "Point Description" field. Click the [Done] button, the point should now appear in the OPC Explorer view.

					Title	FANUC OPC Server Operator's Manual	
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka		Draw	A-40622-00001EN	
04	2018.06.21	S.Matsukura	Data type added.				
03	2017.12.25	T.Hosaka	OPC UA support				
02	2016.01.13	T.Hosaka	Old CNC support and data type added.		FANUC CORPORATION		
Ed.	Date	Design	Description				
Date	2015.09.25	Desig.	T.Hosaka	Check	Apprv.	K.Murata	

3.9.3 Work Offsets Point

Work Offsets status can be read or written.

- 1) Start the Point Configuration Wizard. Click the [Next >>] button. The Path Selection tab appears in the wizard.
- 2) Select [CNC Path 1] in the path for data point list box. Click the [Next >>] button.



05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka							
04	2018.06.21	S.Matsukura	Data type added.							
03	2017.12.25	T.Hosaka	OPC UA support							
02	2016.01.13	T.Hosaka	Old CNC support and data type added.							
Ed.	Date	Design	Description							
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata	FANUC CORPORATION		Sheet. 68/167
									Title	FANUC OPC Server Operator's Manual
									Draw	A-40622-00001EN

- 3) The Data Type Selection tab appears in the wizard.
 Select [Work Offsets] in the Select Data Type list box. Click the [Next >>] button.

Machine Selection Path Selection **Data Type Selection**

When defining a data point, you must identify the type of data the point reflects.
 Provided below is a list of available data types for the machine you have selected.

Please select a point data type in order to continue through this wizard.

MyConfig1\TEST_30iB.TOOL_1_RAD
 CNC Path 1
 Properties: Work Offsets - STRING - R
 Point Name: TOOL_1_RAD
 Point ID: [WZO_1]

Select Data Type

- Custom Macro Common Variable(#100-#199)
- Custom Macro Common Variable(#500-#999)
- Custom Macro Common Variable(#98000-#98499)
- Custom Macro Embedded Macro Variable(#200-#499)
- Custom Macro Local Variable(#1-#33)
- Custom Macro System Variable(#1000-)
- Custom Macro System Variable(#10000-)
- Custom Macro System Variable(#100000-)
- Distance to go Position
- Machine Position
- Main Program Comment
- Main Program Number
- Number of Machined Parts
- Relative Position
- Tool Offsets
- Work Offsets**

					Title	FANUC OPC Server Operator's Manual		
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka		Draw	A-40622-00001EN		
04	2018.06.21	S.Matsukura	Data type added.					
03	2017.12.25	T.Hosaka	OPC UA support					
02	2016.01.13	T.Hosaka	Old CNC support and data type added.					
Ed.	Date	Design	Description			FANUC CORPORATION	Sheet.	69/167
Date	2015.09.25	Desig.	T.Hosaka	Check				

4) The Point Specifics tab appears in the wizard.

Machine Selection	Path Selection	Data Type Selection	Point Specifics																																				
<p>When defining a data point, you must identify specific information about that point. This information can include the memory location of the point, and the type of data the point reflects. Provided below are lists that will help define the specific point information you wish to collect. Please specify the locating information about your point in order to continue through this wizard.</p> <p>MyConfig1\TEST_30iB.TOOL_1_RAD CNC Path 1 Properties: Work Offsets - STRING - R - 0 Point Name: TOOL_1_RAD Point ID: [WZO_0_1_1]</p>																																							
<table border="1"> <thead> <tr> <th>Point Return Type</th> <th>Work Offset Number</th> <th>Axis Number</th> </tr> </thead> <tbody> <tr> <td>STRING</td> <td>0</td> <td>1</td> </tr> <tr> <td></td> <td>0</td> <td>1</td> </tr> <tr> <td></td> <td>1</td> <td>2</td> </tr> <tr> <td></td> <td>2</td> <td>3</td> </tr> <tr> <td></td> <td>3</td> <td>4</td> </tr> <tr> <td></td> <td>4</td> <td>5</td> </tr> <tr> <td></td> <td>5</td> <td>6</td> </tr> <tr> <td></td> <td>6</td> <td>7</td> </tr> <tr> <td></td> <td>P1</td> <td>8</td> </tr> <tr> <td></td> <td>P2</td> <td>9</td> </tr> <tr> <td></td> <td>P3</td> <td>10</td> </tr> </tbody> </table>				Point Return Type	Work Offset Number	Axis Number	STRING	0	1		0	1		1	2		2	3		3	4		4	5		5	6		6	7		P1	8		P2	9		P3	10
Point Return Type	Work Offset Number	Axis Number																																					
STRING	0	1																																					
	0	1																																					
	1	2																																					
	2	3																																					
	3	4																																					
	4	5																																					
	5	6																																					
	6	7																																					
	P1	8																																					
	P2	9																																					
	P3	10																																					
<table border="1"> <thead> <tr> <th>Point Access Type</th> </tr> </thead> <tbody> <tr> <td>R</td> </tr> <tr> <td>W</td> </tr> <tr> <td>RW</td> </tr> </tbody> </table>				Point Access Type	R	W	RW																																
Point Access Type																																							
R																																							
W																																							
RW																																							

Select [R]:read-only, [W]:write only or [RW]:read/write at "Point Access Type".
 Select the "Work Offset Number" and "Axis Number".
 0 : external workpiece origin offset value
 1-6 : G54~G59
 P1-P300 : G54.1 P1~G54.1 P300
 Click the [Next >>] button.

				Title	FANUC OPC Server Operator's Manual			
				Draw	A-40622-00001EN			
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka					
04	2018.06.21	S.Matsukura	Data type added.					
03	2017.12.25	T.Hosaka	OPC UA support					
02	2016.01.13	T.Hosaka	Old CNC support and data type added.	FANUC CORPORATION				
Ed.	Date	Design	Description				Sheet.	70/167
Date	2015.09.25	Desig.	T.Hosaka				Check	

5) The Point Naming tab appears in the wizard.

Machine Selection	Path Selection	Data Type Selection	Point Specifics	Point Naming
-------------------	----------------	---------------------	-----------------	---------------------

When defining a data point, you must identify specific information about that point. This information can include the memory location of the point, and the type of data the point reflects.

Provided below are lists that will help define the specific point information you wish to collect.

Please specify the locating information about your point in order to continue through this wizard.

MyConfig1\TEST_30iB.WORK_1_1
 CNC Path 1
 Properties: Work Offsets - STRING - R - 0
 Point Name: WORK_1_1
 Point ID: [WZO_0_1_1]

Point Name
 New Point being created

Point Description

Enter point name in the "Point Name" field. Enter point description in the "Point Description" field. Click the [Done] button, the point should now appear in the OPC Explorer view.

						Title	FANUC OPC Server Operator's Manual		
05	2020.09.30	R.Imada	The security function of FOCAS2 added.	T.Hosaka		Draw	A-40622-00001EN		
04	2018.06.21	S.Matsukura	Data type added.						
03	2017.12.25	T.Hosaka	OPC UA support						
02	2016.01.13	T.Hosaka	Old CNC support and data type added.						
Ed.	Date	Design	Description			FANUC CORPORATION	Sheet.	71/167	
Date	2015.09.25	Desig.	T.Hosaka	Check	Apprv.				

3.9.4 Program Data Point

CNC Program Data can be read. This is a read-only point.


Data Type	Example
Main Program Number	//CNC_MEM/USER/PATH1/O1000
Main Program Comment	MAIN_PRG
Active Program Number	O0001
Active Program Comment	ACT_PRG

- 1) Start the Point Configuration Wizard. Click the [Next >>] button. The Path Selection tab appears in the wizard.
- 2) Select [CNC Path 1] in the path for data point list box. Click the [Next >>] button.

The screenshot shows the 'Path Selection' tab of a wizard. At the top, there are two tabs: 'Machine Selection' and 'Path Selection', with 'Path Selection' being the active one. Below the tabs, there are three lines of text: 'When defining a data point, you must identify the path upon which the point will exist.', 'Provided below is a list of available paths for the machine you have selected.', and 'Please select a path number for the point in order to continue through this wizard.' Below this text, there are two lines of text: 'MyConfig1\TEST_30iB' and 'CNC Path 1'. Further down, there is a section titled 'Path for Data Point' which contains a list box with two items: 'PMC Path 1' and 'CNC Path 1'. The 'CNC Path 1' item is currently selected and highlighted in blue.

				Title		FANUC OPC Server Operator's Manual		
						Draw		A-40622-00001EN
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka					
04	2018.06.21	S.Matsukura	Data type added.					
03	2017.12.25	T.Hosaka	OPC UA support					
02	2016.01.13	T.Hosaka	Old CNC support and data type added.					
Ed.	Date	Design	Description		FANUC CORPORATION		Sheet.	72/167
Date	2015.09.25	Desig.	T.Hosaka	Check				

- 3) The Data Type Selection tab appears in the wizard.
 Select the data type in the Select Data Type list box. Click the [Next >>] button.



								Title	FANUC OPC Server Operator's Manual
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka					Draw	A-40622-00001EN
04	2018.06.21	S.Matsukura	Data type added.						
03	2017.12.25	T.Hosaka	OPC UA support						
02	2016.01.13	T.Hosaka	Old CNC support and data type added.					FANUC CORPORATION	Sheet. 73/167
Ed.	Date	Design	Description						
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata		

4) The Point Specifics tab appears in the wizard.

Machine Selection	Path Selection	Data Type Selection	Point Specifics
<p>When defining a data point, you must identify specific information about that point. This information can include the memory location of the point, and the type of data the point reflects. Provided below are lists that will help define the specific point information you wish to collect. Please specify the locating information about your point in order to continue through this wizard.</p> <p>MyConfig1\TEST_30iB.WORK_1_1 CNC Path 1 Properties: Main Program Number - STRING - R Point ID: [MN_1]</p>			
<p>Point Return Type</p> <p>STRING</p>			
<p>Point Access Type</p> <p>R</p>			

Click the [Next >>] button.

5) The Point Naming tab appears in the wizard.

Machine Selection	Path Selection	Data Type Selection	Point Specifics	Point Naming
<p>When defining a data point, you must identify specific information about that point. This information can include the memory location of the point, and the type of data the point reflects. Provided below are lists that will help define the specific point information you wish to collect. Please specify the locating information about your point in order to continue through this wizard.</p> <p>MyConfig1\TEST_30iB.MAIN_PRG_NAME CNC Path 1 Properties: Main Program Number - STRING - R Point Name: MAIN_PRG_NAME Point ID: [MN_1]</p>				
<p>Point Name</p> <p>MAIN_PRG_NAME New Point being created</p>				
<p>Point Description</p> <p></p>				

Enter point name in the "Point Name" field. Enter point description in the "Point Description" field. Click the [Done] button, the point should now appear in the OPC Explorer view.


					Title	FANUC OPC Server Operator's Manual		
05	2020.09.30	R.Imada	The security function of FOCAS2 added.	T.Hosaka	Draw	A-40622-00001EN		
04	2018.06.21	S.Matsukura	Data type added.					
03	2017.12.25	T.Hosaka	OPC UA support					
02	2016.01.13	T.Hosaka	Old CNC support and data type added.					
Ed.	Date	Design	Description			FANUC CORPORATION	Sheet.	74/167
Date	2015.09.25	Desig.	T.Hosaka	Check	Apprv.			

3.9.5 Custom Macro Variable Point

Custom Macro Variable status can be read or written.


Data Type
Custom Macro Local Variable (#1-#33)
Custom Macro Embedded Macro Variable (#200-#499)
Custom Macro Common Variable (#100-#199)
Custom Macro Common Variable (#500-#999)
Custom Macro Common Variable (#98000-#98499)
Custom Macro System Variable (#1000-)
Custom Macro System Variable (#10000-)
Custom Macro System Variable (#10000-)

- 1) Start the Point Configuration Wizard. Click the [Next >>] button. The Path Selection tab appears in the wizard.
- 2) Select [CNC Path 1] in the path for data point list box. Click the [Next >>] button.




				Title		FANUC OPC Server Operator's Manual	
				Draw		A-40622-00001EN	
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka				
04	2018.06.21	S.Matsukura	Data type added.				
03	2017.12.25	T.Hosaka	OPC UA support				
02	2016.01.13	T.Hosaka	Old CNC support and data type added.				
Ed.	Date	Design	Description	FANUC CORPORATION		Sheet.	75/167
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata

- 3) The Data Type Selection tab appears in the wizard.
 Select the data type in the Select Data Type list box.
 Click the [Next >>] button.



- 4) The Point Specifics tab appears in the wizard.



				Title	FANUC OPC Server Operator's Manual	
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka	Draw	A-40622-00001EN	
04	2018.06.21	S.Matsukura	Data type added.			
03	2017.12.25	T.Hosaka	OPC UA support			
02	2016.01.13	T.Hosaka	Old CNC support and data type added.	FANUC CORPORATION		Sheet. 76/167
Ed.	Date	Design	Description			
Date	2015.09.25	Desig.	T.Hosaka	Check	Apprv.	K.Murata

Select [R]:read-only, [W]:write only or [RW]:read/write at "Point Access Type".
 Select the "Variable Number" and "Array Size". Click the [Next >>] button.

5) The Point Naming tab appears in the wizard.

Machine Selection	Path Selection	Data Type Selection	Point Specifics	Point Naming
-------------------	----------------	---------------------	-----------------	---------------------

When defining a data point, you must identify specific information about that point. This information can include the memory location of the point, and the type of data the point reflects.

Provided below are lists that will help define the specific point information you wish to collect.

Please specify the locating information about your point in order to continue through this wizard.

MyConfig1\TEST_30iB.MACRO_100_1
 CNC Path 1
 Properties: Custom Macro Common Variable(#100-#199) - STRING - RW - 100
 Point Name: MACRO_100_1
 Point ID: [CMV_100_1]
 Variable Number Range: 100 - 100

Point Name
 New Point being created

Point Description

Enter point name in the "Point Name" field. Enter point description in the "Point Description" field.
 Click the [Done] button, the point should now appear in the OPC Explorer view.

					Title	FANUC OPC Server Operator's Manual									
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka												
04	2018.06.21	S.Matsukura	Data type added.												
03	2017.12.25	T.Hosaka	OPC UA support												
02	2016.01.13	T.Hosaka	Old CNC support and data type added.												
Ed.	Date	Design	Description												
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata					FANUC CORPORATION		Sheet.	77/167

The <null> value of CNC

There is a state called <null> for a variable. It means that no value is defined. It is displayed as "DATA EMPTY" in CNC. The value of "DATA EMPTY" of CNC is indicated as "NULL" by the OPC client.
When writing "DATA EMPTY" to CNC, set the character string "NULL" to the OPC client.

Effective range and display of variable

- *1 The available range of custom points that can be written by the FANUC OPC server depends on the value of parameter F16 (6008#0).
- *2 If writing variable values outside the range of (*1) from the OPC client, a message indicating out of range is displayed in the variable value input field of CNC.
- *3 Even if underflow or overflow is displayed, CNC internally holds the value within the stated range.

In case of 30i/31i/32i/35i/0i-D/0i-F/Power Motion i-A. The number of significant digits is 12. (6008#0=0)

Range of Values(*1)	Display of CNC(*2)	Internal Retainable Range of CNC(*3)
0 < Values < + 0.00000000001	+ UNDERFLOW	0 < Values <= + 10 ⁻³⁰⁸
0 > Values > - 0.00000000001	- UNDERFLOW	0 > Values >= - 10 ⁻³⁰⁸
Values > + 999999999999	+ OVERFLOW	0 < Values <= + 10 ³⁰⁸
Values < - 999999999999	- OVERFLOW	0 > Values >= - 10 ³⁰⁸

In case of 30i/31i/32i/35i/0i-D/0i-F/Power Motion i-A. The number of significant digits is 8. (6008#0=1)

Range of Values(*1)	Display of CNC(*2)	Internal Retainable Range of CNC(*3)
0 < Values < + 0.0000001	+ UNDERFLOW	0 < Values <= + 10 ⁻²⁹
0 > Values > - 0.0000001	- UNDERFLOW	0 > Values >= - 10 ⁻²⁹
Values > + 99999999	+ OVERFLOW	0 < Values <= + 10 ⁴⁷
Values < - 99999999	- OVERFLOW	0 > Values >= - 10 ⁴⁷

In case of 0i-B/0i-C/16i/18i/21i/PowerMate i. The number of significant digits is 8.

Range of Values(*1)	Display of CNC(*2)	Internal Retainable Range of CNC(*3)
0 < Values < + 0.0000001	*****	0 < Values <= + 10 ⁻²⁹
0 > Values > - 0.0000001	*****	0 > Values >= - 10 ⁻²⁹
Values > + 99999999	*****	0 < Values <= + 10 ⁴⁷
Values < - 99999999	*****	0 > Values >= - 10 ⁴⁷

NOTE

There was a case that the value read by the OPC client is displayed as an exponent. It was fixed so that it will not be displayed as an exponent.

				Title		FANUC OPC Server Operator's Manual	
				Draw		A-40622-00001EN	
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka				
04	2018.06.21	S.Matsukura	Data type added.				
03	2017.12.25	T.Hosaka	OPC UA support				
02	2016.01.13	T.Hosaka	Old CNC support and data type added.				
Ed.	Date	Design	Description	FANUC CORPORATION		Sheet.	78/167
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata

3.9.6 Alarm Information Point

CNC Alarm Information can be read. This is a read-only point.

Data Type	Example
Alarm Messages	SW0100 PARAMETER ENABLE SWITCH ON
Alarm Number	SW0100

- 1) Start the Point Configuration Wizard. Click the [Next >>] button. The Path Selection tab appears in the wizard.
- 2) Select [CNC Path 1] in the path for data point list box. Click the [Next >>] button.

Machine Selection

Path Selection

When defining a data point, you must identify the path upon which the point will exist.

Provided below is a list of available paths for the machine you have selected.

Please select a path number for the point in order to continue through this wizard.

MyConfig1\TEST_30iB
CNC Path 1

Path for Data Point

PMC Path 1
CNC Path 1

						Title FANUC OPC Server Operator's Manual			
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka			Draw A-40622-00001EN			
04	2018.06.21	S.Matsukura	Data type added.						
03	2017.12.25	T.Hosaka	OPC UA support						
02	2016.01.13	T.Hosaka	Old CNC support and data type added.						
Ed.	Date	Design	Description			FANUC CORPORATION			
Date	2015.09.25	Desig.	T.Hosaka	Check			Apprv.	K.Murata	Sheet.

- 3) The Data Type Selection tab appears in the wizard.
 Select the data type in the Select Data Type list box.
 Click the [Next >>] button.

Machine Selection Path Selection **Data Type Selection**

When defining a data point, you must identify the type of data the point reflects. Provided below is a list of available data types for the machine you have selected.

Please select a point data type in order to continue through this wizard.
 MyConfig1\TEST_30iB.MACRO_100_1
 CNC Path 1
 Properties: Alarm Messages - STRING - R - 1
 Point ID: [ALMM_1]

Select Data Type

- Alarm Messages
- Alarm Number
- Axis Name
- CNC controlled Axis Count/Path
- CNC Series
- CNC Type
- Custom Macro Common Variable(#100-#199)
- Custom Macro Common Variable(#500-#999)
- Custom Macro Common Variable(#98000-#98499)
- Custom Macro Embedded Macro Variable(#200-#499)
- Custom Macro Local Variable(#1-#33)
- Custom Macro System Variable(#1000-)
- Custom Macro System Variable(#10000-)
- Custom Macro System Variable(#100000-)
- Distance to go Position
- Machine Position

- 4) The Point Specifics tab appears in the wizard.

Machine Selection Path Selection Data Type Selection **Point Specifics**

When defining a data point, you must identify specific information about that point. This information can include the memory location of the point, and the type of data the point reflects. Provided below are lists that will help define the specific point information you wish to collect. Please specify the locating information about your point in order to continue through this wizard.

MyConfig1\TEST_30iB.MACRO_100_1
 CNC Path 1
 Properties: Alarm Messages - STRING - R - 1
 Point ID: [ALMM_1_1]
 Alarm Messages Range: 1 - 1

Point Return Type Alarm Messages **Array Size**

STRING 1 1

Point Access Type

R 1 2 3 4 5 6 7 8 9 10

The Alarm Messages is a fixed value of one.
 Select the "Array Size". Maximum number is 50.

						Title	FANUC OPC Server Operator's Manual			
05	2020.09.30	R.Imada	The security function of FOCAS2 added.	T.Hosaka		Draw	A-40622-00001EN			
04	2018.06.21	S.Matsukura	Data type added.							
03	2017.12.25	T.Hosaka	OPC UA support							
02	2016.01.13	T.Hosaka	Old CNC support and data type added.				FANUC CORPORATION		Sheet.	80/167
Ed.	Date	Design	Description							
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata			

When the CNC Type (Control Types) is 0i-B/C, 16i/18i/21i-A/B or PMi-D/H, and the language other than English and Japanese is selected, alarm number only can be read even if Alarm Messages is selected as Data Type.

If the number of Alarm Messages occurring in the CNC is fewer than the specified number of the array, the empty string (length of the string is 0) is set in the place where the message is not read.

Click the [Next >>] button.

5) The Point Naming tab appears in the wizard.

Machine Selection	Path Selection	Data Type Selection	Point Specifics	Point Naming
-------------------	----------------	---------------------	-----------------	--------------

When defining a data point, you must identify specific information about that point. This information can include the memory location of the point, and the type of data the point reflects.

Provided below are lists that will help define the specific point information you wish to collect.

Please specify the locating information about your point in order to continue through this wizard.

MyConfig1\TEST_30iB.ALM_MSG_1
 CNC Path 1
 Properties: Alarm Messages - STRING - R - 1
 Point Name: ALM_MSG_1
 Point ID: [ALMM_1_1]
 Alarm Messages Range: 1 - 1

Point Name
 New Point being created

Point Description

Enter point name in the "Point Name" field. Enter point description in the "Point Description" field. Click the [Done] button, the point should now appear in the OPC Explorer view.

								Title	FANUC OPC Server Operator's Manual
								Draw	A-40622-00001EN
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka						
04	2018.06.21	S.Matsukura	Data type added.						
03	2017.12.25	T.Hosaka	OPC UA support						
02	2016.01.13	T.Hosaka	Old CNC support and data type added.						
Ed.	Date	Design	Description						
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata	FANUC CORPORATION	Sheet. 81/167

3.9.7 Axis Name Point

CNC Axis Name can be read. This is a read-only point.

- 1) Start the Point Configuration Wizard. Click the [Next >>] button. The Path Selection tab appears in the wizard.
- 2) Select [CNC Path 1] in the path for data point list box. Click the [Next >>] button.

Machine Selection Path Selection

When defining a data point, you must identify the path upon which the point will exist.

Provided below is a list of available paths for the machine you have selected.

Please select a path number for the point in order to continue through this wizard.

MyConfig1\TEST_30iB
CNC Path 1

Path for Data Point

PMC Path 1
CNC Path 1

				Title	FANUC OPC Server Operator's Manual
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka	Draw	A-40622-00001EN
04	2018.06.21	S.Matsukura	Data type added.		
03	2017.12.25	T.Hosaka	OPC UA support		
02	2016.01.13	T.Hosaka	Old CNC support and data type added.		
Ed.	Date	Design	Description	FANUC CORPORATION	
Date	2015.09.25	Desig.	T.Hosaka		
		Check		Apprv.	K.Murata

- 3) The Data Type Selection tab appears in the wizard.
 Select [Axis Name] in the Select Data Type list box. Click the [Next >>] button.

Machine Selection Path Selection **Data Type Selection**

When defining a data point, you must identify the type of data the point reflects.
 Provided below is a list of available data types for the machine you have selected.

Please select a point data type in order to continue through this wizard.
 MyConfig1\TEST_30iB.ALM_MSG_1
 CNC Path 1
 Properties: Axis Name - STRING - R - 1
 Point ID: [AXISNAME_1_1]

Select Data Type

- Axis Name
- CNC controlled Axis Count/Path
- CNC Series
- CNC Type
- Custom Macro Common Variable(#100-#199)
- Custom Macro Common Variable(#500-#999)
- Custom Macro Common Variable(#98000-#98499)
- Custom Macro Embedded Macro Variable(#200-#499)
- Custom Macro Local Variable(#1-#33)
- Custom Macro System Variable(#1000-)
- Custom Macro System Variable(#10000-)
- Custom Macro System Variable(#100000-)
- Distance to go Position
- Machine Position
- Main Program Comment
- Main Program Number

- 4) The Point Specifics tab appears in the wizard.

Machine Selection Path Selection Data Type Selection **Point Specifics**

When defining a data point, you must identify specific information about that point. This information can include the memory location of the point, and the type of data the point reflects.
 Provided below are lists that will help define the specific point information you wish to collect.
 Please specify the locating information about your point in order to continue through this wizard.

MyConfig1\TEST_30iB.ALM_MSG_1
 CNC Path 1
 Properties: Axis Name - STRING - R - 1
 Point ID: [AXISNAME_1_1]

Point Return Type Axis Number

STRING 1

Point Access Type

R 1

2

3

4

5

6

7

8

9

10

Select the "Axis Number". Click the [Next >>] button.

						Title	FANUC OPC Server Operator's Manual			
05	2020.09.30	R.Imada	The security function of FOCAS2 added.	T.Hosaka		Draw	A-40622-00001EN			
04	2018.06.21	S.Matsukura	Data type added.							
03	2017.12.25	T.Hosaka	OPC UA support							
02	2016.01.13	T.Hosaka	Old CNC support and data type added.				FANUC CORPORATION		Sheet.	83/167
Ed.	Date	Design	Description							
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata			

5) The Point Naming tab appears in the wizard.

Machine Selection | Path Selection | Data Type Selection | Point Specifics | Point Naming

When defining a data point, you must identify specific information about that point. This information can include the memory location of the point, and the type of data the point reflects.

Provided below are lists that will help define the specific point information you wish to collect.

Please specify the locating information about your point in order to continue through this wizard.

MyConfig1\TEST_30iB.AXIS_1
CNC Path 1
Properties: Axis Name - STRING - R - 1
Point Name: AXIS_1
Point ID: [AXISNAME_1_1]

Point Name
 New Point being created

Point Description

Enter point name in the "Point Name" field. Enter point description in the "Point Description" field. Click the [Done] button, the point should now appear in the OPC Explorer view.

												Title	FANUC OPC Server Operator's Manual			
												Draw	A-40622-00001EN			
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka													
04	2018.06.21	S.Matsukura	Data type added.													
03	2017.12.25	T.Hosaka	OPC UA support													
02	2016.01.13	T.Hosaka	Old CNC support and data type added.									FANUC CORPORATION		Sheet.	84/167	
Ed.	Date	Design	Description				Check		Apprv.	K.Murata						
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.		K.Murata								

3.9.8 Position Information Point

CNC Position Information can be read. This is a read-only point.

Data Type
Absolute Position
Relative Position
Machine Position
Distance to go Position

- 1) Start the Point Configuration Wizard. Click the [Next >>] button. The Path Selection tab appears in the wizard.
- 2) Select [CNC Path 1] in the path for data point list box. Click the [Next >>] button.

Machine Selection
Path Selection

When defining a data point, you must identify the path upon which the point will exist.

Provided below is a list of available paths for the machine you have selected.

Please select a path number for the point in order to continue through this wizard.

MyConfig1\TEST_30iB
CNC Path 1

Path for Data Point

PMC Path 1
CNC Path 1

						Title	FANUC OPC Server Operator's Manual		
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka			Draw	A-40622-00001EN		
04	2018.06.21	S.Matsukura	Data type added.						
03	2017.12.25	T.Hosaka	OPC UA support						
02	2016.01.13	T.Hosaka	Old CNC support and data type added.						
Ed.	Date	Design	Description			FANUC CORPORATION	Sheet.	85/167	
Date	2015.09.25	Desig.	T.Hosaka	Check					Apprv.

- 3) The Data Type Selection tab appears in the wizard.
 Select the data type in the Select Data Type list box. Click the [Next >>] button.

Machine Selection
Path Selection
Data Type Selection

When defining a data point, you must identify the type of data the point reflects.
 Provided below is a list of available data types for the machine you have selected.

Please select a point data type in order to continue through this wizard.

MyConfig1\TEST_30iB.AXIS_1
 CNC Path 1
 Properties: Machine Position - STRING - R
 Point ID: [MA_1]

Select Data Type

- Absolute Position
- Active Program Comment
- Active Program Number
- Alarm Messages
- Alarm Number
- Axis Name
- CNC controlled Axis Count/Path
- CNC Series
- CNC Type
- Custom Macro Common Variable(#100-#199)
- Custom Macro Common Variable(#500-#999)
- Custom Macro Common Variable(#98000-#98499)
- Custom Macro Embedded Macro Variable(#200-#499)
- Custom Macro Local Variable(#1-#33)
- Custom Macro System Variable(#1000-)
- Custom Macro System Variable(#10000-)
- Custom Macro System Variable(#100000-)
- Distance to go Position
- Machine Position
- Main Program Comment
- Main Program Number
- Number of Machined Parts
- Relative Position
- Tool Offsets
- Work Offsets

				Title	FANUC OPC Server Operator's Manual			
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka	Draw	A-40622-00001EN			
04	2018.06.21	S.Matsukura	Data type added.					
03	2017.12.25	T.Hosaka	OPC UA support					
02	2016.01.13	T.Hosaka	Old CNC support and data type added.					
Ed.	Date	Design	Description			FANUC CORPORATION	Sheet.	86/167
Date	2015.09.25	Desig.	T.Hosaka	Check				

4) The Point Specifics tab appears in the wizard.

Machine Selection Path Selection Data Type Selection **Point Specifics**

When defining a data point, you must identify specific information about that point. This information can include the memory location of the point, and the type of data the point reflects.
 Provided below are lists that will help define the specific point information you wish to collect.
 Please specify the locating information about your point in order to continue through this wizard.

MyConfig1\TEST_30iB.AXIS_1
 CNC Path 1
 Properties: Machine Position - STRING - R - 1
 Point ID: [MA_1_1]
 Axis Range: 1 - 32

Point Return Type	Axis Number	Array Size
STRING	1	1
	1	1
	2	2
	3	3
	4	4
	5	5
	6	6
	7	7
	8	8
	9	9
	10	10

Point Access Type
 R

Select the "Axis Number" and "Array Size". Click the [Next >>] button.

5) The Point Naming tab appears in the wizard.

Machine Selection Path Selection Data Type Selection Point Specifics **Point Naming**

When defining a data point, you must identify specific information about that point. This information can include the memory location of the point, and the type of data the point reflects.
 Provided below are lists that will help define the specific point information you wish to collect.
 Please specify the locating information about your point in order to continue through this wizard.

MyConfig1\TEST_30iB.ABS_POS_1
 CNC Path 1
 Properties: Machine Position - STRING - R - 1
 Point Name: ABS_POS_1
 Point ID: [MA_1_1]
 Axis Range: 1 - 32

Point Name
 New Point being created

Point Description

Enter point name in the "Point Name" field. Enter point description in the "Point Description" field. Click the [Done] button, the point should now appear in the OPC Explorer view.

						Title	FANUC OPC Server Operator's Manual		
						Draw	A-40622-00001EN		
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka						
04	2018.06.21	S.Matsukura	Data type added.						
03	2017.12.25	T.Hosaka	OPC UA support						
	02	2016.01.13	T.Hosaka	Old CNC support and data type added.			FANUC CORPORATION		
Ed.	Date	Design	Description			Sheet.			
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata		

3.9.9 PMC Data Point

PMC bit or PMC byte status can be read or written. Some PMC address is read only.

Data Type
PMC Bit
PMC Byte
PMC 2Byte
PMC 4Byte

- 1) Start the Point Configuration Wizard. Click the [Next >>] button. The Path Selection tab appears in the wizard.
- 2) Select the PMC Path number in Path for Data Point list box. PMC Path number is listed by the format of [PMC Path <PMC Path Number>]. Click the [Next >>] button.

Machine Selection Path Selection

When defining a data point, you must identify the path upon which the point will exist.

Provided below is a list of available paths for the machine you have selected.

Please select a path number for the point in order to continue through this wizard.

MyConfig1\TEST_30iB
PMC Path 1

Path for Data Point

- PMC Path 1
- CNC Path 1

						Title	FANUC OPC Server Operator's Manual			
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka			Draw	A-40622-00001EN			
04	2018.06.21	S.Matsukura	Data type added.							
03	2017.12.25	T.Hosaka	OPC UA support							
02	2016.01.13	T.Hosaka	Old CNC support and data type added.							
Ed.	Date	Design	Description				FANUC CORPORATION		Sheet.	88/167
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.				

- 3) The Data Type Selection tab appears in the wizard.
 Select the data type in the Select Data Type list box.
 Click the [Next >>] button.

Machine Selection Path Selection **Data Type Selection**

When defining a data point, you must identify the type of data the point reflects.
 Provided below is a list of available data types for the machine you have selected.

Please select a point data type in order to continue through this wizard.
 MyConfig1\TEST_30iB
 PMC Path 1
 Properties: PMC Bit - RW
 Point ID: [PMCBIT_1]

Select Data Type

- PMC 2Byte
- PMC 4Byte
- PMC Alarm Messages
- PMC Alarm Number
- PMC Bit**
- PMC Byte

						Title	FANUC OPC Server Operator's Manual				
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka								
04	2018.06.21	S.Matsukura	Data type added.							Draw	A-40622-00001EN
03	2017.12.25	T.Hosaka	OPC UA support								
02	2016.01.13	T.Hosaka	Old CNC support and data type added.								
Ed.	Date	Design	Description							FANUC CORPORATION	Sheet. 89/167
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata				

4) The Point Specifics tab appears in the wizard.

Machine Selection	Path Selection	Data Type Selection	Point Specifics
<p>When defining a data point, you must identify specific information about that point. This information can include the memory location of the point, and the type of data the point reflects. Provided below are lists that will help define the specific point information you wish to collect. Please specify the locating information about your point in order to continue through this wizard.</p> <p>MyConfig1\TEST_30iB PMC Path 1 Properties: PMC Bit - BOOL - R - R Point ID: [PMCBIT_R_0_0_1]</p>			
<p>Point Return Type</p> <p>BOOL STRING</p>	<p>PMC Address Type</p> <p>R G F Y X A</p>	<p>PMC Start Address</p> <p>0 (0 - 59999)</p>	<p>Bit Position</p> <p>0 1 2 3 4 5 6 7</p>
<p>Point Access Type</p> <p>R W RW</p>	<p>R T K C D</p>		

Select "Point Return Type".

Select the "PMC Address".

Select [R]:read-only, [W]:write only or [RW]:read/write at "Point Access Type". According to the selected tab "Data Type Selection", only [R] is selectable.

Select the "PMC Start Address", and "Array Size" or "Bit Position".

Click the [Next >>] button.

				Title	FANUC OPC Server Operator's Manual			
				Draw	A-40622-00001EN			
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka					
04	2018.06.21	S.Matsukura	Data type added.					
03	2017.12.25	T.Hosaka	OPC UA support					
02	2016.01.13	T.Hosaka	Old CNC support and data type added.	FANUC CORPORATION			Sheet.	90/167
Ed.	Date	Design	Description					
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata	

3.9.10 PMC Alarm Information Point

PMC Alarm Information can be read. This is a read-only point.

Data Type	Example
PMC Alarm Messages	ER01 PROGRAM DATA ERROR (PMC2)
PMC Alarm Number	ER01

- 1) Start the Point Configuration Wizard. Click the [Next >>] button. The Path Selection tab appears in the wizard.
- 2) Select the PMC Path number in Path for Data Point list box. PMC Path number is listed by the format of [PMC Path <PMC Path Number>]. Click the [Next >>] button.

Machine Selection Path Selection

When defining a data point, you must identify the path upon which the point will exist.

Provided below is a list of available paths for the machine you have selected.

Please select a path number for the point in order to continue through this wizard.

MyConfig1\TEST_30iB
 PMC Path 1

Path for Data Point

PMC Path 1
 CNC Path 1

					Title	FANUC OPC Server Operator's Manual
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka		Draw	A-40622-00001EN
04	2018.06.21	S.Matsukura	Data type added.			
03	2017.12.25	T.Hosaka	OPC UA support			
02	2016.01.13	T.Hosaka	Old CNC support and data type added.			
Ed.	Date	Design	Description		FANUC CORPORATION	Sheet. 92/167
Date	2015.09.25	Desig.	T.Hosaka	Check	Apprv. K.Murata	

- 3) The Data Type Selection tab appears in the wizard.
 Select the data type in the Select Data Type list box.
 Click the [Next >>] button.

Machine Selection | Path Selection | **Data Type Selection**

When defining a data point, you must identify the type of data the point reflects.
 Provided below is a list of available data types for the machine you have selected.

Please select a point data type in order to continue through this wizard.
 MyConfig1\TEST_30iB.PMC_BIT_R0000_2
 PMC Path 1
 Properties: PMC Alarm Messages - STRING - R - 1
 Point ID: [PMCALMM_1]

Select Data Type

- PMC 2Byte
- PMC 4Byte
- PMC Alarm Messages**
- PMC Alarm Number
- PMC Bit
- PMC Byte

					Title	FANUC OPC Server Operator's Manual				
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka							
04	2018.06.21	S.Matsukura	Data type added.							Draw
03	2017.12.25	T.Hosaka	OPC UA support							
02	2016.01.13	T.Hosaka	Old CNC support and data type added.							
Ed.	Date	Design	Description							FANUC CORPORATION
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata	Sheet.	93/167	

4) The Point Specifics tab appears in the wizard.

Machine Selection | Path Selection | Data Type Selection | **Point Specifics**

When defining a data point, you must identify specific information about that point. This information can include the memory location of the point, and the type of data the point reflects.
 Provided below are lists that will help define the specific point information you wish to collect.
 Please specify the locating information about your point in order to continue through this wizard.

MyConfig1\TEST_30iB.PMC_BIT_R0000_2
 PMC Path 1
 Properties: PMC Alarm Messages - STRING - R - 1
 Point ID: [PMCALMM_1_1]
 Alarm Messages Range: 1 - 1

Point Return Type **PMC Alarm Messages** **Array Size**

STRING 1 1

Point Access Type

R

1
2
3
4
5
6
7
8
9
10

The PMC Alarm Messages is a fixed value of one.

Select the "Array Size". Maximum number is 50.

When the CNC Type (Control Types) is 0i-B/C, 16i/18i/21i-A/B or PMi-D/H, and the language other than English and Japanese is selected, alarm number only can be read even if Alarm Messages is selected as Data Type.


Click the [Next >>] button.

								Title	FANUC OPC Server Operator's Manual
								Draw	A-40622-00001EN
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka						
04	2018.06.21	S.Matsukura	Data type added.						
03	2017.12.25	T.Hosaka	OPC UA support						
02	2016.01.13	T.Hosaka	Old CNC support and data type added.						
Ed.	Date	Design	Description					FANUC CORPORATION	Sheet. 94/167
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata		

3.9.11 Number of Machined Parts Point


Number of Machined Parts status can be read. This is a read-only point.

- 1) Start the Point Configuration Wizard. Click the [Next >>] button. The Path Selection tab appears in the wizard.
- 2) Select [CNC Path 1] in the path for data point list box. Click the [Next >>] button.



									Title	FANUC OPC Server Operator's Manual			
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka						Draw	A-40622-00001EN	FANUC CORPORATION	Sheet.	96/167
04	2018.06.21	S.Matsukura	Data type added.										
03	2017.12.25	T.Hosaka	OPC UA support										
02	2016.01.13	T.Hosaka	Old CNC support and data type added.										
Ed.	Date	Design	Description										
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata						

- 3) The Data Type Selection tab appears in the wizard.
 Select [Number of Machined Parts] in the Select Data Type list box. Click the [Next >>] button.



					Title	FANUC OPC Server Operator's Manual			
					Draw	A-40622-00001EN			
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka						
04	2018.06.21	S.Matsukura	Data type added.						
03	2017.12.25	T.Hosaka	OPC UA support						
02	2016.01.13	T.Hosaka	Old CNC support and data type added.						
Ed.	Date	Design	Description		FANUC CORPORATION			Sheet.	97/167
Date	2015.09.25	Desig.	T.Hosaka	Check					

4) The Point Specifics tab appears in the wizard.

Machine Selection	Path Selection	Data Type Selection	Point Specifics
-------------------	----------------	---------------------	-----------------

When defining a data point, you must identify specific information about that point. This information can include the memory location of the point, and the type of data the point reflects.
 Provided below are lists that will help define the specific point information you wish to collect.
 Please specify the locating information about your point in order to continue through this wizard.

MyConfig1\TEST_30iB
 CNC Path 1
 Properties: Number of Machined Parts - UINT32 - R
 Point ID: [NMP_1]

Point Return Type

UINT32
 STRING

Point Access Type

R

Select "Point Return Type". Usually, [UINT32] is used.
 Click the [Next >>] button.

5) The Point Naming tab appears in the wizard.

Machine Selection	Path Selection	Data Type Selection	Point Specifics	Point Naming
-------------------	----------------	---------------------	-----------------	--------------

When defining a data point, you must identify specific information about that point. This information can include the memory location of the point, and the type of data the point reflects.
 Provided below are lists that will help define the specific point information you wish to collect.
 Please specify the locating information about your point in order to continue through this wizard.

MyConfig1\TEST_30iB.PARTS_NUM
 CNC Path 1
 Properties: Number of Machined Parts - UINT32 - R
 Point Name: PARTS_NUM
 Point ID: [NMP_1]

Point Name
 PARTS_NUM New Point being created

Point Description

Enter point name in the "Point Name" field. Enter point description in the "Point Description" field.
 Click the [Done] button, the point should now appear in the OPC Explorer view.

					Title	FANUC OPC Server Operator's Manual			
05	2020.09.30	R.Imada	The security function of FOCAS2 added.	T.Hosaka	Draw	A-40622-00001EN			
04	2018.06.21	S.Matsukura	Data type added.						
03	2017.12.25	T.Hosaka	OPC UA support						
02	2016.01.13	T.Hosaka	Old CNC support and data type added.		FANUC CORPORATION			Sheet.	98/167
Ed.	Date	Design	Description						
Date	2015.09.25	Desig.	T.Hosaka	Check	Apprv.	K.Murata			

3.9.12 P-CODE Variable Point

P-CODE Variable status can be read or written. Some P-CODE Variable status is read only. The range of values that can be set varies depending on CNC.

In case of 30i / 31i / 32i / 35i / 0i-D / 0i-F / Power Motion i-A

Data Type	Access Type
P-CODE Control Variable (#8500-#8999)	R
P-CODE Variable (#10000-#19999)	R, W, RW
Extended P-CODE Variable (#20000-#89999)	

In case of 0i-B / 0i-C / 16i / 18i / 21i / PowerMate i

Data Type	Access Type
P-CODE Control Variable (#8500-#8999)	R
P-CODE Variable (#10000-#19999)	R, W, RW
Extended P-CODE Variable (#20000-#85531)	

- 1) Start the Point Configuration Wizard. Click the [Next >>] button. The Path Selection tab appears in the wizard.
- 2) Select [CNC Path 1] in the path for data point list box.

Machine Selection Path Selection

When defining a data point, you must identify the path upon which the point will exist.

Provided below is a list of available paths for the machine you have selected.

Please select a path number for the point in order to continue through this wizard.

MyConfig1\TEST_30iB
CNC Path 1

Path for Data Point

- PMC Path 1
- CNC Path 1**

Click the [Next >>] button.

Ed.	Date	Design	Description	Title	Draw	Sheet.	99/167
				FANUC OPC Server Operator's Manual			
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka				
04	2018.06.21	S.Matsukura	Data type added.				
03	2017.12.25	T.Hosaka	OPC UA support				
02	2016.01.13	T.Hosaka	Old CNC support and data type added.				
				FANUC CORPORATION			
Date	2015.09.25	Desig.	T.Hosaka	Check	Apprv.	K.Murata	

- 3) The Data Type Selection tab appears in the wizard.
Select the data type in the Select Data Type list box.

Machine Selection Path Selection **Data Type Selection**

When defining a data point, you must identify the type of data the point reflects.
Provided below is a list of available data types for the machine you have selected.

Please select a point data type in order to continue through this wizard.

IncgMyConfig1
CNC Path 1
Properties: P-CODE Variable(#10000-#19999) - STRING - RW - 10000
Point ID: [PCV_10000_1]
Variable Number Range: 10000 - 10000

Select Data Type

- Custom Macro Local Variable(#1-#33)
- Custom Macro System Variable(#1000-)
- Custom Macro System Variable(#10000-)
- Custom Macro System Variable(#100000-)
- Distance to go Position
- Extended P-CODE Variable(#20000-#89999)
- Machine Position
- Main Program Comment
- Main Program Number
- Number of Machined Parts
- Operator Messages
- P-CODE Control Variable(#8500-#8999)
- P-CODE Variable(#10000-#19999)**
- Relative Position
- Tool Offsets
- Work Offsets

Click the [Next >>] button.

				Title		FANUC OPC Server Operator's Manual	
				Draw		A-40622-00001EN	
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka				
04	2018.06.21	S.Matsukura	Data type added.				
03	2017.12.25	T.Hosaka	OPC UA support				
02	2016.01.13	T.Hosaka	Old CNC support and data type added.				
Ed.	Date	Design	Description				
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata
FANUC CORPORATION						Sheet.	100/167

5) The Point Naming tab appears in the wizard.

Machine Selection	Path Selection	Data Type Selection	Point Specifics	Point Naming
-------------------	----------------	---------------------	-----------------	--------------

When defining a data point, you must identify specific information about that point. This information can include the memory location of the point, and the type of data the point reflects.

Provided below are lists that will help define the specific point information you wish to collect.

Please specify the locating information about your point in order to continue through this wizard.

MyConfig1\TEST_30iB.PCODE_10000_1
 CNC Path 1
 Properties: P-CODE Variable (#10000-) - STRING - RW - 10000
 Point Name: PCODE_10000_1
 Point ID: [PCV_10000_1]
 Variable Number Range: 10000 - 10000

Point Name
 New Point being created

Point Description

Enter point name in the "Point Name" field. Enter point description in the "Point Description" field. Click the [Done] button, the point should now appear in the OPC Explorer view.


For "The <null> value of CNC", "Effective range and display of variable", refer to the chapter of "Custom Macro Variable Point".

					Title	FANUC OPC Server Operator's Manual	
					Draw	A-40622-00001EN	
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka				
04	2018.06.21	S.Matsukura	Data type added.				
03	2017.12.25	T.Hosaka	OPC UA support				
02	2016.01.13	T.Hosaka	Old CNC support and data type added.		FANUC CORPORATION		Sheet. 102/167
Ed.	Date	Design	Description				
Date	2015.09.25	Desig.	T.Hosaka	Check			

3.9.13 Operator Messages Point

Operator messages can be read. This is a read-only point.

- 1) Start the Point Configuration Wizard. Click the [Next >>] button. The Path Selection tab appears in the wizard.
- 2) Select the PMC Path number in Path for Data Point list box. PMC Path number is listed by the format of [PMC Path <PMC Path Number>].



Click the [Next >>] button.

						Title	FANUC OPC Server Operator's Manual		
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka			Draw	A-40622-00001EN		
04	2018.06.21	S.Matsukura	Data type added.						
03	2017.12.25	T.Hosaka	OPC UA support						
02	2016.01.13	T.Hosaka	Old CNC support and data type added.			FANUC CORPORATION			
Ed.	Date	Design	Description						Sheet.
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata		

- 3) The Data Type Selection tab appears in the wizard.
Select the data type in the Select Data Type list box.

<div style="display: flex; justify-content: space-between; border-bottom: 1px solid gray; margin-bottom: 5px;"> Machine Selection Path Selection Data Type Selection </div> <div style="padding: 5px;"> <p>When defining a data point, you must identify the type of data the point reflects. Provided below is a list of available data types for the machine you have selected.</p> <p>Please select a point data type in order to continue through this wizard.</p> <p>MyConfig1\TEST_30iB CNC Path 1</p> <p>Select Data Type</p> <div style="border: 1px solid gray; padding: 5px; min-height: 150px;"> <ul style="list-style-type: none"> Custom Macro Local Variable(#1-#33) Custom Macro System Variable(#1000-) Custom Macro System Variable(#10000-) Custom Macro System Variable(#100000-) Distance to go Position Extended P-CODE Variable (#20000-) Machine Position Main Program Comment Main Program Number Number of Machined Parts <li style="border: 2px solid red;">Operator Messages P-CODE Control Variable (#8500-) P-CODE Variable (#10000-) Relative Position Tool Offsets Work Offsets </div> </div>
--

Click the [Next >>] button.

						Title	FANUC OPC Server Operator's Manual		
						Draw	A-40622-00001EN		
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka						
04	2018.06.21	S.Matsukura	Data type added.						
							FANUC CORPORATION		
03	2017.12.25	T.Hosaka	OPC UA support						
02	2016.01.13	T.Hosaka	Old CNC support and data type added.						
Ed.	Date	Design	Description				Sheet.	104/167	
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata		

4) The Point Specifics tab appears in the wizard.

Machine Selection	Path Selection	Data Type Selection	Point Specifics																																							
<p>When defining a data point, you must identify specific information about that point. This information can include the memory location of the point, and the type of data the point reflects. Provided below are lists that will help define the specific point information you wish to collect. Please specify the locating information about your point in order to continue through this wizard.</p> <p>MyConfig1\TEST_30iB CNC Path 1 Properties: Operator Messages - STRING - R - 1 Point ID: [OPMSG_1_1] Operator Messages Range: 1 - 1</p>																																										
<table border="1"> <thead> <tr> <th>Point Return Type</th> <th>Operator Messages</th> <th>Array Size</th> </tr> </thead> <tbody> <tr> <td>STRING</td> <td>1</td> <td>1</td> </tr> <tr> <td></td> <td>1</td> <td>1</td> </tr> <tr> <td></td> <td></td> <td>2</td> </tr> <tr> <td></td> <td></td> <td>3</td> </tr> <tr> <td></td> <td></td> <td>4</td> </tr> <tr> <td></td> <td></td> <td>5</td> </tr> <tr> <td></td> <td></td> <td>6</td> </tr> <tr> <td></td> <td></td> <td>7</td> </tr> <tr> <td></td> <td></td> <td>8</td> </tr> <tr> <td></td> <td></td> <td>9</td> </tr> <tr> <td></td> <td></td> <td>10</td> </tr> <tr> <td></td> <td></td> <td>11</td> </tr> </tbody> </table>				Point Return Type	Operator Messages	Array Size	STRING	1	1		1	1			2			3			4			5			6			7			8			9			10			11
Point Return Type	Operator Messages	Array Size																																								
STRING	1	1																																								
	1	1																																								
		2																																								
		3																																								
		4																																								
		5																																								
		6																																								
		7																																								
		8																																								
		9																																								
		10																																								
		11																																								
<table border="1"> <thead> <tr> <th>Point Access Type</th> </tr> </thead> <tbody> <tr> <td>R</td> </tr> <tr> <td></td> </tr> </tbody> </table>				Point Access Type	R																																					
Point Access Type																																										
R																																										

Only "1" can be specified for "Operator Messages".
 Select the "Array Size". Maximum number is 17.
 Click the [Next >>] button.

						Title	FANUC OPC Server Operator's Manual				
						Draw	A-40622-00001EN				
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka								
04	2018.06.21	S.Matsukura	Data type added.								
03	2017.12.25	T.Hosaka	OPC UA support								
02	2016.01.13	T.Hosaka	Old CNC support and data type added.								
Ed.	Date	Design	Description							FANUC CORPORATION	
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata	Sheet.	105/167		

5) The Point Naming tab appears in the wizard.

Machine Selection	Path Selection	Data Type Selection	Point Specifics	Point Naming
<p>When defining a data point, you must identify specific information about that point. This information can include the memory location of the point, and the type of data the point reflects.</p> <p>Provided below are lists that will help define the specific point information you wish to collect.</p> <p>Please specify the locating information about your point in order to continue through this wizard.</p>				
<pre>MyConfig1\TEST_30IB.OP_MSG_1 CNC Path 1 Properties: Operator Messages - STRING - R - 1 Point Name: OP_MSG_1 Point ID: [OPMSG_1_1] Operator Messages Range: 1 - 1</pre>				
<p>Point Name</p> <input type="text" value="OP_MSG_1"/> New Point being created				
<p>Point Description</p> <input type="text"/>				

Enter point name in the "Point Name" field. Enter point description in the "Point Description" field. Click the [Done] button, the point should now appear in the OPC Explorer view.

The format of the operator message is as follows.

External Operator Messages: "OPR" + Message Number + " " + Message Body

Macro Messages: "MCR" + Message Number + " " + Message Body

If the number of Operator Messages occurring in the CNC is fewer than the specified number of the array, the empty string (length of the string is 0) is set in the place where the message is not read.

Example: Array size set by configurator is 6, CNC generates 1 External Operator message and 1 Macro message occurs.

String[0]	External Operator Message	"OPR2000 EXT_MES1"
String[1]	Macro Message	"MCR0 ABC"
String[2]	Empty String	" "
String[3]	Empty String	" "
String[4]	Empty String	" "
String[5]	Empty String	" "

						Title	FANUC OPC Server Operator's Manual	
05	2020.09.30	R.Imada	The security function of FOCAS2 added.	T.Hosaka		Draw	A-40622-00001EN	
04	2018.06.21	S.Matsukura	Data type added.					
03	2017.12.25	T.Hosaka	OPC UA support					
02	2016.01.13	T.Hosaka	Old CNC support and data type added.					
Ed.	Date	Design	Description			FANUC CORPORATION	Sheet.	106/167
Date	2015.09.25	Desig.	T.Hosaka	Check	Apprv.			

- 3) The Data Type Selection tab appears in the wizard.
Select the data type in the Select Data Type list box.

Machine Selection Path Selection **Data Type Selection**

When defining a data point, you must identify the type of data the point reflects.
Provided below is a list of available data types for the machine you have selected.

Please select a point data type in order to continue through this wizard.

MyConfig1\TEST_30iB
CNC Path 1
Properties: CNC Status (Mode) - STRING - R
Point ID: [CNCMD_1]

Select Data Type

- Absolute Position
- Active Program Comment
- Active Program Number
- Alarm Messages
- Alarm Number
- Axis Name
- CNC controlled Axis Count/Path
- CNC Series
- CNC Status (Emergency)
- CNC Status (Mode)
- CNC Status (Operation)
- CNC Type
- Custom Macro Common Variable(#100-#199)
- Custom Macro Common Variable(#500-#999)
- Custom Macro Common Variable(#98000-#98499)
- Custom Macro Embedded Macro Variable(#200-#499)

Click the [Next >>] button.

- 4) The Point Specifics tab appears in the wizard.

Machine Selection Path Selection Data Type Selection **Point Specifics**

When defining a data point, you must identify specific information about that point. This information can include the memory location of the point, and the type of data the point reflects.
Provided below are lists that will help define the specific point information you wish to collect.
Please specify the locating information about your point in order to continue through this wizard.

MyConfig1\TEST_30iB
CNC Path 1
Properties: CNC Status (Mode) - STRING - R
Point ID: [CNCMD_1]

Point Return Type

STRING

Point Access Type


R

						Title	FANUC OPC Server Operator's Manual		
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka			Draw	A-40622-00001EN		
04	2018.06.21	S.Matsukura	Data type added.						
03	2017.12.25	T.Hosaka	OPC UA support						
02	2016.01.13	T.Hosaka	Old CNC support and data type added.			FANUC CORPORATION		Sheet.	109/167
Ed.	Date	Design	Description						
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata		

3.11 User Account Configuration


This screen is used to set up a user account that you specify when OPC UA server connection. User account that has been set in this screen will be reflected in the configuration file that is exported to the OPC server.

User account settings screen, click the [Tools] menu, click the drop-down menu [User Account Configuration].



3.11.1 User Account

It is the list screen of a registered user account. Additional user account, edit, and delete. The number of user accounts that can be registered is 50 pieces.



[Delete]

Delete the selected user account.
"admin" user cannot be deleted.

05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka							
04	2018.06.21	S.Matsukura	Data type added.							
03	2017.12.25	T.Hosaka	OPC UA support							
02	2016.01.13	T.Hosaka	Old CNC support and data type added.							
Ed.	Date	Design	Description							FANUC CORPORATION
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata	Sheet.	113/167	

4.6 Help Menu

The help menu currently has only one selection, which is [About]. The [About] box indicates the product name and version.




4.7 SVR Date

OPC client is notified of the information of FANUC OPC server.
Description of each data is as follows.

Point Name	Type	Description
SVR.LASTREADTIME	Long	Read processing time at the time of the read request
SVR.LICENSE_APPLIED_TO	String	Fixed to 0
SVR.LICENSE_EXPIRATION	String	License expiration date Fixed to the "9999/12/31"
SVR.LICENSE_NUMBER_OF_MACHINE_ALLOWED	String	Connectable CNC number Fixed at 100
SVR.LICENSE_STATUS	String	License status Fixed to the "Licensed"
SVR.LICENSE_USERS_ALLOWED	String	Connectable Clients number Fixed to 11
SVR.MODE_OPC_UA	String	mode state of FANUC OPC server True : OPC UA mode False : OPC Classic mode
SVR.MODE_SERVICE	String	Service mode state of FANUC OPC server True : Service mode False : Application mode
SVR.NUMBER_OF_ACTIVE_MACHINES	String	Connection CNC number that has been set in the FANUC OPC Configurator
SVR.NUMBER_OF_LOADED_MACHINES	String	CNC number that have been read as a connection object
SVR.OUTPUTQUEUECOUNT	Long	Fixes to 0
SVR.SERVER_VERSION	String	FANUC OPC Server Version
SVR.STAT_NUM_CHG_PER_PD	Long	Number of Change Notifications

				Title	FANUC OPC Server Operator's Manual			
				Draw	A-40622-00001EN			
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka					
04	2018.06.21	S.Matsukura	Data type added.					
03	2017.12.25	T.Hosaka	OPC UA support					
02	2016.01.13	T.Hosaka	Old CNC support and data type added.					
Ed.	Date	Design	Description	FANUC CORPORATION			Sheet.	120/167
Date	2015.09.25	Desig.	T.Hosaka					

- 1) Configuration settings screen of FANUC OPC Configurator, set the [OPC UA Mode] check box. Please display method of the screen, see "3.7 configuration settings" on "III. Setting".



OPC UA mode checkbox


Check box is enabled : Operating in the OPC UA mode

Check box is disabled : Operating in the OPC Classic mode

Set the other setting items in the configuration settings, press the [Done] button.

- 2) Save the settings.
Click the [File] menu, and then click the [Save Configuration] from the drop-down menu.
Settings are saved to the MyConfig1.fs2.
- 3) Click the [File] menu, and then click [Export] in the drop-down menu.
- 4) Click the [OK] button to close the export Dialog window.
- 5) Click [All Programs],[FANUC OPC server],[FANUC OPC server] of Windows, Start the FANUC OPC server.
- 6) Current mode of operation, the screen title of FANUC OPC server and can be found in the SVR information of the OPC client.

Title	SVR.MODE_OPC_UA	Description
OPC UA	True	Operating in the OPC UA mode
OPC Classic	False	Operating in the OPC Classic mode



Item ID	Data Type	Value
SVR.MODE_OPC_UA	String	True
SVR.MODE_SERVICE	String	False
SVR.NUMBER_OF_ACTIVE...	String	1
SVR.NUMBER_OF_LOADE...	String	1

				Title	FANUC OPC Server Operator's Manual	
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka	Draw	A-40622-00001EN	
04	2018.06.21	S.Matsukura	Data type added.			
03	2017.12.25	T.Hosaka	OPC UA support			
02	2016.01.13	T.Hosaka	Old CNC support and data type added.	FANUC CORPORATION		
Ed.	Date	Design	Description			Sheet.
Date	2015.09.25	Desig.	T.Hosaka	Check	Apprv.	K.Murata

5.4 OPC UA mode connection

This chapter describes the procedure of connection with the OPC UA client. OPC UA client is described using the Softing company "OPC UA Client". Connect to the OPC Classic of the client (eg OPC Quick Client) is the same as the FANUC OPC server version 2.0.0. Please and method of connecting the OPC Quick Client refers to the "1.4 OPC client of operation check" in the "III. Setting".

5.4.1 Discovery of the OPC server

Connection from the OPC UA client to the OPC UA server, specify the endpoint of the OPC UA server. If the endpoint is known in advance, you can specify the endpoint directly. Discovery function of the endpoint of the OPC UA server searches for the OPC server If you do not know is located in the OPC UA standard. Use the discovery feature allows you to search the OPC UA server running on any personal computer. Search for LocalDiscoveryServer (below LDS) will be installed at the same time with the FANUC OPC server. OPC UA client using the Discovery Function, you can search for FANUC OPC server.


NOTE

Windows XP cannot use this discovery feature.
Connection from the OPC UA client in Windows XP, please connect by specifying the endpoint directly.

This section describes how to use the discovery function.

- 1) When you start the FANUC OPC server in UA mode, it will be issued a certificate of FANUC OPC server.
Certificate Folder : C:\ProgramData\FANUC\OPCServer\PKI\CA\certs
File name of the issued certificate is "MyCertificate.der".
- 2) Issued FANUC OPC server of the certificate will also be created to reject folder of the certificate issued at the same time as LDS.
Reject Folder : C:\ProgramData\OPC Foundation\UA\Discovery\pki\rejected
The name of the file that is created is created with the following rules.


									Title	FANUC OPC Server Operator's Manual	
									Draw	A-40622-00001EN	
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka								
04	2018.06.21	S.Matsukura	Data type added.								
03	2017.12.25	T.Hosaka	OPC UA support								
02	2016.01.13	T.Hosaka	Old CNC support and data type added.								
Ed.	Date	Design	Description				FANUC CORPORATION		Sheet.	124/167	
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata				



- After that the file of reject folder of LDS of the certificate is a FANUC OPC server of the certificate is confirmed, move it to the trust folder of LDS.

Trust Folder : C:\ProgramData\OPC Foundation\UA\Discovery\pk\trusted\certs

- Search for the FANUC OPC server from the OPC UA client.




5.4.2 OPC server connection(security disabled)

Connect the OPC UA client and FANUC OPC server.


Disable the security settings to connect to the server.

- Select the "opc.tcp-None-None" from the search was FANUC OPC server security mode.


						Title	FANUC OPC Server Operator's Manual			
05	2020.09.30	R.Imada				Draw	A-40622-00001EN			
04	2018.06.21	S.Matsukura								
03	2017.12.25	T.Hosaka								
02	2016.01.13	T.Hosaka								
Ed.	Date	Design	Description			FANUC CORPORATION			Sheet.	125/167
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata			



- 2) Select the "UserName" from the "User Identity" field, enter "admin" in the "User Name" field, enter "admin" (is displayed ●●●●●) to the "Password" field.



- 3) [Validate Connection] button is connected to success When a green check mark appears, press.




05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka								
04	2018.06.21	S.Matsukura	Data type added.							Draw	A-40622-00001EN
03	2017.12.25	T.Hosaka	OPC UA support								
02	2016.01.13	T.Hosaka	Old CNC support and data type added.								
Ed.	Date	Design	Description							FANUC CORPORATION	Sheet. 126/167
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata				

5.4.3 OPC server connection(security enabled)


Enable the security settings to connect to the server.

- 1) Select the "opc.tcp-Sign-Basic128Rsa15" from the search was FANUC OPC server security mode.



- 2) Select the "UserName" from the "User Identity" field, enter "admin" in the "User Name" field, enter "admin" (is displayed ●●●●●) to the "Password" field. (No security and the same)
- 3) If you are using a Softing OPC UA Client, you will see the following screen and press the [Validate Connection] button.

In this case, select the "Add Certificate To Trusted Store", then press the OK button.



When you press the OK button, the trust folder of Softing OPC UA Client, FANUC OPC server of the certificate is created.

Trust Folder : C:\ProgramData\Softing\OpcClient\pki\trusted\certs


Create File Name : FANUCOPCServer@ComputerName [Thumbprint number].der

Thumbprint number : Thumbprint number of FANUC OPC server's certificate


Example)

FANUCOPCServer@WIN-BB2CH2V6TER [DF11A43CD19F723026EF66F8A2C2C5FC9DB4526A].der

						Title	FANUC OPC Server Operator's Manual					
						Draw	A-40622-00001EN					
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka									
04	2018.06.21	S.Matsukura	Data type added.									
03	2017.12.25	T.Hosaka	OPC UA support									
02	2016.01.13	T.Hosaka	Old CNC support and data type added.									
Ed.	Date	Design	Description							FANUC CORPORATION	Sheet.	127/167
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata					




- 4) [Validate Connection] button red "X" mark appears, and connection failure.



NOTE

Connection failure in this case, is normal.
 Since the OPC UA client certificate has not been authenticated to the OPC UA server, and connection failure.

- 5) If the connection fails, to reject folder of FANUC OPC server, certificate of OPC UA client is created.
 Reject Folder : C:\ProgramData\FANUC\OPCServer\PKI\CA\rejected
 File name is the same as the naming convention of the file name of the 2) of "5.4.1 search of the OPC server".
- 6) The OPC UA client's certificate in the reject folder of FANUC OPC server, move it to the trust folder of FANUC OPC server.
 Trust Folder : C:\ProgramData\FANUC\OPCServer\PKI\CA\certs
- 7) Again, it is a successful connection when you see a green check mark by pressing the [Validate Connection] button.



NOTE

Same operation in other security mode.
 SignAndEncrypt-Basic128Rsa15
 Sign-Basic256
 SignAndEncrypt-Basic256

				Title	FANUC OPC Server Operator's Manual		
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka	Draw	A-40622-00001EN		
04	2018.06.21	S.Matsukura	Data type added.				
03	2017.12.25	T.Hosaka	OPC UA support				
02	2016.01.13	T.Hosaka	Old CNC support and data type added.	FANUC CORPORATION		Sheet.	128/167
Ed.	Date	Design	Description				
Date	2015.09.25	Desig. T.Hosaka	Check	Apprv. K.Murata			

5.5 Certificate authentication


This chapter describes the exchange of certificates that have been made in the OPC UA standard.

OPC UA standards, at the time of connection of the OPC UA server and the OPC UA client, make sure both of the certificate, has established a security on the communication by authentication.

In addition, LDS also be authenticated to verify the certificate of the OPC UA server, you have to notice the existence of the OPC UA server to the OPC UA client.

5.5.1 OPC server certificate registration to the LDS

OPC UA server certificate, and save it in the trust folder of LDS.



①FANUC OPC server certificate, once, will be created in the reject folder of LDS.


②The certificate of the LDS reject folder, by moving to trust folder of LDS, to register the FANUC OPC server.

LDS to that OPC UA server is registered, you can search the OPC UA server from the OPC UA client.

					Title	FANUC OPC Server Operator's Manual	
					Draw	A-40622-00001EN	
05	2020.09.30	R.Imada	The security function of FOCAS2 added.	T.Hosaka			
04	2018.06.21	S.Matsukura	Data type added.				
03	2017.12.25	T.Hosaka	OPC UA support				
02	2016.01.13	T.Hosaka	Old CNC support and data type added.				
Ed.	Date	Design	Description			FANUC CORPORATION	Sheet. 129/167
Date	2015.09.25	Desig.	T.Hosaka	Check	Apprv. K.Murata		

5.5.2 Certificate authentication of the OPC UA server


The FANUC OPC server's certificate by OPC UA client is stored in the trust folder, to allow a connection to the FANUC OPC server.



① FANUC OPC server certificate, once, will be created in the reject folder of the OPC UA client.

② A certificate of reject folder of the OPC UA client, by moving to trust folder of the OPC UA client and allow the connection of the FANUC OPC server.

"Softing OPC UA Client" is a movement from the reject folder to trust folder, by selected on the confirmation screen to the user, have been moved.




NOTE

How to move the certificate of the OPC UA client is dependent on the specifications of the OPC UA client to use.

						Title	FANUC OPC Server Operator's Manual			
05	2020.09.30	R.Imada				Draw	A-40622-00001EN			
04	2018.06.21	S.Matsukura								
03	2017.12.25	T.Hosaka								
02	2016.01.13	T.Hosaka								
Ed.	Date	Design	Description			FANUC CORPORATION			Sheet.	130/167
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata			


5.5.3 Certificate authentication of the OPC UA Client

If the OPC UA client is connected with available OPC UA server and the security mode, the certificate of the OPC UA client, be to save the trust folder of the OPC UA server, to allow a connection to the OPC UA server.




- ① OPC UA client certificates, once, will be created in the reject folder of the OPC UA server.
- ② A certificate of reject folder of the OPC UA server, by moving to trust folder of the OPC UA server, allows the connection with the OPC UA client.

						Title	FANUC OPC Server Operator's Manual			
						Draw	A-40622-00001EN			
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka							
04	2018.06.21	S.Matsukura	Data type added.							
03	2017.12.25	T.Hosaka	OPC UA support							
02	2016.01.13	T.Hosaka	Old CNC support and data type added.							
Ed.	Date	Design	Description			FANUC CORPORATION			Sheet.	131/167
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata			




- 4) FANUC OPC service tool is started.
Make sure that the service in the operating mode has been selected, and then click the switch button.




When switching to the Windows service is complete, the "current mode" display will change to "service".

- 5) FANUC OPC server (FANUCOPCServer) will start running on a Windows service.



						Title	FANUC OPC Server Operator's Manual			
05	2020.09.30	R.Imada	The security function of FOCAS2 added.	T.Hosaka		Draw	A-40622-00001EN			
04	2018.06.21	S.Matsukura	Data type added.							
03	2017.12.25	T.Hosaka	OPC UA support							
02	2016.01.13	T.Hosaka	Old CNC support and data type added.				FANUC CORPORATION		Sheet.	133/167
Ed.	Date	Design	Description							
Date	2015.09.25	Desig.	T.Hosaka	Check	Apprv.	K.Murata				



					Title	FANUC OPC Server Operator's Manual						
					Draw	A-40622-00001EN						
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka									
04	2018.06.21	S.Matsukura	Data type added.									
03	2017.12.25	T.Hosaka	OPC UA support									
02	2016.01.13	T.Hosaka	Old CNC support and data type added.									
Ed.	Date	Design	Description							FANUC CORPORATION	Sheet.	135/167
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata					

7

DCOM Setting


This chapter describes DCOM summary, for the DCOM method of setting the server PC and the client PC. If you want to connect in OPC Classic clients from other personal computer to the server of OPC Classic mode requires DCOM setting.

This setting method in the case of server / client PC is "Windows 7 Professional 32bit OS".

7.1 Summary

The DCOM, a Microsoft's technology for communication between software components on a computer which is distributed on the network (distributed object technology).

Another client PC and server PC (FANUC OPC server) (OPC Quick Client) will communicate with Ethernet through DCOM.



7.2 Server/Client PC sharing settings

If you are using DCOM on the WORKGROUP, and set the following three points in both of the server / client PC.

- 1) The same account name, and log in with the same password.
- 2) Set the login password sure.
- 3) To belong to the same WORKGROUP.

7.3 Client PC Settings

This section describes the configuration of the client PC.

The client PC assumes that the following software is installed.

- OPC Core Components
- Software toolbox OPC Quick Client


							Title	FANUC OPC Server Operator's Manual			
							Draw	A-40622-00001EN			
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka								
04	2018.06.21	S.Matsukura	Data type added.								
03	2017.12.25	T.Hosaka	OPC UA support								
02	2016.01.13	T.Hosaka	Old CNC support and data type added.								
Ed.	Date	Design	Description				FANUC CORPORATION			Sheet.	136/167
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata				

7.3.1 Windows Firewall Exceptions settings


This section describes the Windows Firewall exception settings on the client PC.

Firewall and preferably disable it unnecessary environment. If you disable, exceptional settings of the firewall, you do not need.

- 1) Open the [Control Panel], click the [Windows Firewall].




- 2) Click "Allow a program or feature through Windows Firewall".




						Title	FANUC OPC Server Operator's Manual			
05	2020.09.30	R.Imada			The security function of FOCAS2 added. T.Hosaka	Draw	A-40622-00001EN			
04	2018.06.21	S.Matsukura		Data type added.						
03	2017.12.25	T.Hosaka		OPC UA support						
02	2016.01.13	T.Hosaka			Old CNC support and data type added.					
Ed.	Date	Design	Description			FANUC CORPORATION		Sheet.	137/167	
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata			

- 3) Click [Allow another program...].
If the button cannot click, and then click the button to click the [Change Settings] button.




- 4) "Program:" Select the "OPC Quick Client" from the list, and click the [Add] button.




						Title	FANUC OPC Server Operator's Manual		
05	2020.09.30	R.Imada		The security function of FOCAS2 added.	T.Hosaka	Draw	A-40622-00001EN		
04	2018.06.21	S.Matsukura		Data type added.					
03	2017.12.25	T.Hosaka		OPC UA support					
02	2016.01.13	T.Hosaka		Old CNC support and data type added.		FANUC CORPORATION	Sheet.	138/167	
Ed.	Date	Design	Description						
Date	2015.09.25	Desig.	T.Hosaka	Check					

5) "Allowed programs and features:" the has been added to the list "OPC Quick Client" is set as follows, and then click the [OK] button.




6) Click the "Advanced settings".




						Title	FANUC OPC Server Operator's Manual			
						Draw	A-40622-00001EN			
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka							
04	2018.06.21	S.Matsukura	Data type added.							
03	2017.12.25	T.Hosaka	OPC UA support							
02	2016.01.13	T.Hosaka	Old CNC support and data type added.							
Ed.	Date	Design	Description			FANUC CORPORATION			Sheet.	139/167
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata			

- 9) Set as follows, and then click [Next >] button.
 "Specific local ports:" To do this, enter the "135".




- 10) Set as follows, and then click [Next >] button.




					Title	FANUC OPC Server Operator's Manual			
					Draw	A-40622-00001EN			
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka						
04	2018.06.21	S.Matsukura	Data type added.						
03	2017.12.25	T.Hosaka	OPC UA support						
02	2016.01.13	T.Hosaka	Old CNC support and data type added.						
Ed.	Date	Design	Description			FANUC CORPORATION		Sheet.	141/167
Date	2015.09.25	Desig.	T.Hosaka	Check					

- 2) "Component Services", "computer", right-click on "My Computer", and then click "Properties" from the pop-up menu.




- 3) Click on the "Default Properties" tab, and set as follows.




						Title	FANUC OPC Server Operator's Manual			
05	2020.09.30	R.Imada				Draw	A-40622-00001EN			
04	2018.06.21	S.Matsukura								
03	2017.12.25	T.Hosaka								
02	2016.01.13	T.Hosaka				FANUC CORPORATION				
Ed.	Date	Design	Description						Sheet.	144/167
Date	2015.09.25	Desig.	T.Hosaka	Check	Apprv.				K.Murata	

- 4) "COM security" Click on the tab, and then click [Edit Limits...] button of "Access permissions".




- 5) "Group or user names:" After selecting from the list "ANONYMOUS LOGON", "Permissions for ANONYMOUS LOGON" the set as follows, and then click the [OK] button.




						Title	FANUC OPC Server Operator's Manual				
05	2020.09.30	R.Imada	The security function of FOCAS2 added.	T.Hosaka		Draw	A-40622-00001EN				
04	2018.06.21	S.Matsukura	Data type added.								
03	2017.12.25	T.Hosaka	OPC UA support								
02	2016.01.13	T.Hosaka	Old CNC support and data type added.			FANUC CORPORATION	Sheet.	145/167			
Ed.	Date	Design	Description								
Date	2015.09.25	Desig.	T.Hosaka	Check					Apprv.	K.Murata	

6) Click [Edit Default ...] button of "Access permissions".




7) Click the [Add] button.




					Title	FANUC OPC Server Operator's Manual
					Draw	A-40622-00001EN
05	2020.09.30	R.Imada	The security function of FOCAS2 added.	T.Hosaka		
04	2018.06.21	S.Matsukura	Data type added.			
03	2017.12.25	T.Hosaka	OPC UA support			
02	2016.01.13	T.Hosaka	Old CNC support and data type added.			
Ed.	Date	Design	Description		FANUC CORPORATION	
Date	2015.09.25	Desig.	T.Hosaka	Check	Apprv.	K.Murata
					Sheet.	146/167

- 8) "Enter the object names to select(examples):" to set the following, and then click the [OK] button.
 "Enter the object names to select(examples):" To do this, enter the "Everyone".




- 9) "Group or user names:" After selecting the "Everyone" from the list, the "Permissions for Everyone" set as follows, and then click the [OK] button.




						Title	FANUC OPC Server Operator's Manual		
						Draw	A-40622-00001EN		
05	2020.09.30	R.Imada	The security function of FOCAS2 added.	T.Hosaka					
04	2018.06.21	S.Matsukura	Data type added.						
03	2017.12.25	T.Hosaka	OPC UA support						
02	2016.01.13	T.Hosaka	Old CNC support and data type added.						
Ed.	Date	Design	Description			FANUC CORPORATION		Sheet.	147/167
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata		

2) Click the "Change advanced sharing settings".




3) Set as follows, and then click the [Save Changes] button. Change only the settings in the frame. In the following "Home or Work" has become the current profile, but the "public" is the case of the current profile, to enable the there of settings.




4) This enabled the completion of the network search / file sharing settings above. Close the open window.

						Title	FANUC OPC Server Operator's Manual			
05	2020.09.30	R.Imada		The security function of FOCAS2 added.	T.Hosaka	Draw	A-40622-00001EN			
04	2018.06.21	S.Matsukura		Data type added.						
03	2017.12.25	T.Hosaka		OPC UA support						
02	2016.01.13	T.Hosaka		Old CNC support and data type added.		FANUC CORPORATION			Sheet.	150/167
Ed.	Date	Design	Description							
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata			

2) Click "Allow a program or feature through Windows Firewall".




3) Click [Allow another program...].
If the button cannot click, and then click the button to click the [Change Settings] button.




						Title	FANUC OPC Server Operator's Manual
05	2020.09.30	R.Imada	The security function of FOCAS2 added.	T.Hosaka		Draw	A-40622-00001EN
04	2018.06.21	S.Matsukura	Data type added.				
03	2017.12.25	T.Hosaka	OPC UA support				
02	2016.01.13	T.Hosaka	Old CNC support and data type added.				
Ed.	Date	Design	Description			FANUC CORPORATION	Sheet. 152/167
Date	2015.09.25	Desig.	T.Hosaka	Check	Apprv. K.Murata		

- 4) "Program:" Select the "FANUC OPC Server" from the list, and click the [Add] button.




- 5) "Allowed programs and features:" the has been added to the list "FANUC OPC Server" is set as follows, and then click the [OK] button.




					Title	FANUC OPC Server Operator's Manual			
05	2020.09.30	R.Imada	The security function of FOCAS2 added.	T.Hosaka	Draw	A-40622-00001EN			
04	2018.06.21	S.Matsukura	Data type added.						
03	2017.12.25	T.Hosaka	OPC UA support						
02	2016.01.13	T.Hosaka	Old CNC support and data type added.			FANUC CORPORATION		Sheet.	153/167
Ed.	Date	Design	Description						
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata		

6) Click "Allow a program or feature through Windows Firewall".




7) Click [Allow another program...].
If the button cannot click, and then click the button to click the [Change Settings] button.




						Title	FANUC OPC Server Operator's Manual
05	2020.09.30	R.Imada	The security function of FOCAS2 added.	T.Hosaka	Draw	A-40622-00001EN	FANUC CORPORATION
04	2018.06.21	S.Matsukura	Data type added.				
03	2017.12.25	T.Hosaka	OPC UA support				
02	2016.01.13	T.Hosaka	Old CNC support and data type added.				
Ed.	Date	Design	Description			FANUC CORPORATION	Sheet. 154/167
Date	2015.09.25	Desig.	T.Hosaka	Check	Apprv.		

8) Click the [Browse...] button.




9) Open the: "C:\Windows\System32" folder, after selecting the "OpcEnum" file, and then click [Open] button.

Extension is displayed is "OpcEnum.exe" file.




						Title	FANUC OPC Server Operator's Manual		
05	2020.09.30	R.Imada	The security function of FOCAS2 added.	T.Hosaka		Draw	A-40622-00001EN		
04	2018.06.21	S.Matsukura	Data type added.						
03	2017.12.25	T.Hosaka	OPC UA support						
02	2016.01.13	T.Hosaka	Old CNC support and data type added.				FANUC CORPORATION		
Ed.	Date	Design	Description			Sheet.			
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata		

- 10) "Program:" Select the "OPC Server Enumerator 1.10" from the list, and click the [Add] button.



- 11) "Allowed programs and features:" the has been added to the list " OPC Server Enumerator 1.10" is set as follows, and then click the [OK] button.




- 12) Is an exception settings the completion of the Windows firewall or more. Close the open window.

7.4.3 DCOM settings


This section describes the DNS settings on the server PC.

					Title	FANUC OPC Server Operator's Manual		
05	2020.09.30	R.Imada	The security function of FOCAS2 added. T.Hosaka		Draw	A-40622-00001EN		
04	2018.06.21	S.Matsukura	Data type added.					
03	2017.12.25	T.Hosaka	OPC UA support					
02	2016.01.13	T.Hosaka	Old CNC support and data type added.					
Ed.	Date	Design	Description			FANUC CORPORATION	Sheet.	156/167
Date	2015.09.25	Desig.	T.Hosaka	Check	Apprv.			

7) Click the [Add] button.




8) "Enter the object names to select(examples):" to set the following, and then click the [OK] button.
 "Enter the object names to select(examples):" To do this, enter the "Everyone".




						Title	FANUC OPC Server Operator's Manual			
05	2020.09.30	R.Imada	The security function of FOCAS2 added.	T.Hosaka		Draw	A-40622-00001EN			
04	2018.06.21	S.Matsukura	Data type added.							
03	2017.12.25	T.Hosaka	OPC UA support							
02	2016.01.13	T.Hosaka	Old CNC support and data type added.				FANUC CORPORATION		Sheet.	160/167
Ed.	Date	Design	Description							
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata			

- 9) "Group or user names:" After selecting the "Everyone" from the list, the "Permissions for Everyone" set as follows, and then click the [OK] button.



- 10) Click the [Edit Limits...] button of "Launch and Activation Permissions".



						Title	FANUC OPC Server Operator's Manual			
05	2020.09.30	R.Imada	The security function of FOCAS2 added.	T.Hosaka		Draw	A-40622-00001EN			
04	2018.06.21	S.Matsukura	Data type added.							
03	2017.12.25	T.Hosaka	OPC UA support							
02	2016.01.13	T.Hosaka	Old CNC support and data type added.				FANUC CORPORATION		Sheet.	161/167
Ed.	Date	Design	Description							
Date	2015.09.25	Desig.	T.Hosaka	Check		Apprv.	K.Murata			

